

AUTOMATIC ENGINE CONTROL FOR DIESEL/GAS ENGINES

The ECU®-9957N engine control provides complete automation and safety monitoring of a gas or diesel engine. The ECU®-9957N controls the starter and fuel thus completely taking the operator out of the picture. A built in speed switch controls both starter disengagement and overspeed protection.

ECU®-57N

**ONE VERSION FOR
12 AND 24 VDC**

APPLICATIONS: Generator Control Panels, Automatic Engine Systems

FEATURES:

- Single or Multi-crank modes are field adjustable
- Built in speed switch
- Grounded or positive HWT/LOP inputs
- Low oil pressure and high water temp override during cranking
- Wide temperature range -40C to +85C
- Epoxy encapsulated module for excellent field reliability
- 1 AMP Relays for annunciator outputs




ECU®-57N A COMPLETE AUTOMATIC ENGINE CONTROL

The ECU®-9957N covers just about all the essential engine control functions that are asked for in most specifications.

The ECU®-9957N automatically cranks, starts and monitors an engine for Overcrank, Overspeed, High Water Temperature and Low Oil Pressure. Any crank timing sequence is accomplished by using the multiple or single crank modes in conjunction with the timer adjustments. A built in speed switch uses a magnetic pickup to monitor engine speed for crank disconnect

and overspeed. The bypass timer/logic assures Low Oil Pressure and High Water Temp override during the crank period and an additional adjustable period after crank disconnect before shutdown actually occurs. The ECU-9957N expands to as many faults as required by using the Engine Alarm Input/Output.


**SAMPLE ECU®-9957N APPLICATION:
MONITORING SYSTEM BATTERY VOLTAGE**




The above illustrates the ECU®-9957N engine control with an energized to run engine. Placing the control switch in MANUAL or closure of the Remote Start Contacts while in AUTO initiates the Crank mode. The Fuel and Starter Relays are energized causing the engine to begin cranking. If the engine does not start in the allotted time, as determined by the Crank Cycle Adjust and Dip Switch setting, the Overcrank Fault occurs, and the Fuel and Starter Relays are turned off. If during cranking the internal speed switch detects a speed equal to or above the Crank Disconnect Adjustment Setting the Starter Relay turns off, the LOP/HWT delay timer is initiated. After this delay period if the LOP or HWT switch closes the engine will shutdown immediately. If the internal speed switch detects a speed equal to or above the Overspeed Adjustment Setting the engine is shutdown immediately. To stop the engine or to clear a fault condition place the control switch in the Off position.

SPECIFICATIONS:
 VOLTAGE RANGE - 9 TO 28 VOLTS
 MAGNETIC PICKUP - 250 TO 8500 HERTZ
 STARTER AND FUEL OUTPUTS - 5 AMPS MAX
 LAMP OUTPUTS (TOTAL) - 1 AMP MAX

ECU®-9957N TERMINAL OUT



PHYSICAL DIMENSIONS



ORDERING INFORMATION:
 ORDER BY SPECIFYING: ECU®-9957N

**ECU® IS A REGISTERED TRADEMARK OF
ENGINEERING CONCEPTS UNLIMITED, INC.**