

# DYNAGEN<sup>®</sup>

control solutions you can trust

## TE410 User Manual



**TOUGH**Series  
Digital Generator Controllers



Manual Revision: 7.0.0  
Min. FW Revision: 1.92.07  
Date Released: 2019-09-25  
© 2019 DynaGen Technologies Inc

# Table of Contents

<b>1 Introduction</b>	<b>5</b>
1.1 Specifications .....	5
<b>2 Installation</b>	<b>7</b>
2.1 General Wiring Notes .....	8
2.2 Terminal Descriptions .....	8
2.3 Wiring Harnesses .....	11
2.4 Typical Wiring Diagram .....	12
2.5 Typical Wiring Diagram with RelayPak .....	13
2.6 Wiring Considerations .....	14
2.6.1 Remote Start Contact (Start/Stop).....	14
2.6.2 Emergency Stop Wiring.....	14
2.6.3 Universal Sensor.....	15
2.6.4 CAN Bus Wiring.....	16
2.6.5 Modbus Wiring.....	18
2.6.6 Current Transformers.....	19
2.6.7 RelayPak (Optional).....	21
2.6.8 Speed Inputs .....	22
<b>3 Pumping Applications</b>	<b>23</b>
3.1 Manual Speed Control .....	23
3.2 Automatic Speed Control .....	24
3.2.1 Autostarting on Floats .....	24
3.2.2 Ramp up and Intermediate Speed.....	26
3.2.3 Process Control using Engine Speed.....	27
3.3 Speed Limiting .....	27
3.4 Electronic Engines .....	27
<b>4 Using the Controller</b>	<b>29</b>
4.1 Modes, Starting and Stopping .....	30
4.1.1 Cranking Behaviour.....	31
4.2 Speed Control Page / Tank Display .....	31
4.3 Four Parameter Display Pages .....	31
4.4 DM1 Page .....	32
4.5 Using Cooldown Mode .....	32
4.6 Warnings .....	33
4.7 Failures .....	33

4.8 Event Log .....	34
<b>5 Settings .....</b>	<b>39</b>
5.1 Operator Setup .....	39
5.2 Application Menu .....	41
5.2.1 Tank Level / Float Application Menu.....	41
Function Menu.....	41
Throttling Menu.....	41
Transducer Menu.....	42
Closed Loop Menu.....	43
Set Scheduler Menu.....	44
Long Time Run Menu.....	44
5.2.2 Wind Machine Application Menu.....	44
5.3 Switched Inputs .....	45
5.3.1 Configurable Inputs.....	49
5.4 Switched Outputs .....	49
5.4.1 Group Outputs.....	52
5.4.2 Pull and Hold Coil.....	52
5.5 Sensors .....	53
5.5.1 Engine Temperature.....	53
5.5.2 Oil Pressure .....	54
5.5.3 Fuel Level .....	54
5.5.4 Engine Speed.....	55
Front Panel Speed Control.....	57
5.5.5 Battery .....	58
5.5.6 Auxiliary Sensors.....	60
Fault Monitor Example.....	64
Start on Low Example.....	65
Output on High Example.....	66
5.5.7 Custom Sensor Tables.....	67
5.6 Timers .....	68
5.6.1 Engine Logic .....	68
Preheat Mode.....	69
False Restart.....	69
OFF Button Function.....	70
Idle .....	71
Warmup Idle.....	71
Idle Inhibit.....	72
5.6.2 Schedulers .....	72
Exerciser .....	72
Weekly Scheduler.....	74
Long Time Run.....	74
5.6.3 Maintenance .....	74
5.7 AC Monitor .....	75
5.7.1 Generator Voltage.....	75
AC Voltage Select.....	77
5.7.2 Generator Frequency.....	77
RPM / Frequency Select.....	78
5.7.3 Generator Current.....	79
Basic Alarms.....	80
IDMT .....	80

Load Imbalance.....	81
Dummy Load.....	82
EPS Supplying Load.....	82
<b>5.8 Communications .....</b>	<b>82</b>
5.8.1 CAN Bus (J1939).....	82
5.8.2 MOD Bus (RS485).....	83
<b>5.9 Other Config .....</b>	<b>83</b>
5.9.1 Password .....	83
5.9.2 Settings Name.....	84
5.9.3 Process Control.....	84
5.9.4 Pump System.....	85
<b>6 Troubleshooting .....</b>	<b>87</b>

## User Guide

# 1 Introduction

The TOUGH series controllers are designed to provide complete control, protection, AC metering, and engine instrumentation for both standard and electronic engines. The module is easily configured using either the front panel buttons or our RapidCore Configuration software. TOUGH Series controllers are ideally suited for severe duty applications where reliability is critical such as mobile and stationary generators.



Tier 4 Ready



**Features and Functions:**

- 5 Year Warranty
  - SAE J1939 CAN Bus Protocol
  - RPM via J1939, Magnetic Pickup, or Generator
  - Speed control offset for electronic engines
  - Autostart on low battery and other sensors
  - Trim feature for AC monitoring and sensors
  - Maintenance counter
  - Exerciser Clock
  - 150 Event Log
  - Conformally coated for protection against moisture
- Gasket for water ingress protection resistance
  - Free RapidCore Configuration Software
  - Fast and rugged installation clips
  - Passcode protected
  - Automatic shutdowns and warnings
  - Manual and Remote start
  - Momentary Start / Stop inputs
  - Pre-heat and many other configurable timers
  - Accepts common senders (VDO, Datcon, S&W)
  - Custom senders configurable with RapidCore Configuration software


**Displays:**

- Engine Temperature
  - Oil Pressure
  - Fuel Level
- Engine Speed
  - AC Metering
  - Battery Voltage
- Real Time Clock
  - Engine Hours
  - Time to Maintenance
- J1939 DTCs + Custom Text
  - Custom Senders
  - Warnings and Failures

## 1.1 Specifications

The TOUGH Series controllers were rigorously tested to ensure durability, reliability and functionality. The following specifications are a brief summary of the standards to which the controller has been tested. For complete details on the testing performed please contact DYNAGEN.

**Testing Specifications**

Specification	Rating
Electrical Transients	SAE1113-11
Thermal Shock and Cycling	SAE1455
Vibration Profiles	SAE1455
Electric Static Discharge	SAE1113-13: +/-8KV Direct Discharge, +/-15kV Air gap discharge
UL	 UL 6200 recognized component. Consult factory for UL conditions of acceptability.

**Physical Specifications**

Specification	Rating
Operating Temperature	-40 to +158°F (-40 to +70°C)
LCD Viewing Temperature	-4 to +158°F (-20 to +70°C ) (Optional heater available, call factory)

Specification	Rating
Weight Weight w/ RelayPak	0.83lb (0.38kg) 1.32lb (0.60kg)
Dimensions - controller (no gasket) - controller w/ gasket - controller w/ gasket and RelayPak	4.17" x 6.50" x 1.38" (10.59cm x 16.51cm x 3.51cm) 4.41" x 6.79" x 1.38" (11.20cm x 17.25cm x 3.51cm) 4.41" x 6.79" x 3.33" (11.20cm x 17.25cm x 8.46cm)

**Electrical Specifications**

Specification	Rating
Operating Voltage	5.5 ~ 36 VDC
Standby Current (Minimum)	Auto Mode: 60mA @ 12VDC, 38mA @ 24VDC (back lighting off) Off Mode: 80mA @ 12VDC, 45mA @ 24VDC (back lighting off) Actual consumption could be more depending on connected sensors and other I/O.
Switched Inputs	+Battery, Ground, Open, Closed
Switched Outputs	+Battery @ 1A Max
Low Resistance Sensors	0 ~ 750Ohm
High Resistance Sensors	0 ~ 7,500Ohm
Universal Sensors	0 ~ 750Ohm, 0 ~ 7,500Ohm, 0 ~ 5 VDC, 4 ~ 20mA
Magnetic Pickup	10 ~ 10,000Hz at 1 ~ 50 VAC
AC Voltage (Line-To-Line)	UL Approved Range: 50 ~ 600 VAC True RMS, Accuracy: 2% Full Scale. Non - UL Range: 50 ~ 670 VAC Do not connect more than 600VAC to the controller for UL approved installations or 700VAC for locations where UL is not required.
AC Current	0 ~ 5A (Current Transformer), Accuracy: 1% Full Scale
Communications	SAE J1939 (Tier II, III, IV)
External Sensor Power	TG410 only: 5 VDC at a max load of 200mA

## 2 Installation

Generator systems contain high voltage circuitry and precautions to protect against electrical shock should be taken. Failing to power down and lock out equipment can cause damage, injury or death.





**WARNING:** Wiring of this controller should be performed by qualified electricians only.

The following general electrical safety precaution should be followed:

- Do a thorough inspection of the area before performing any maintenance.
- Keep fluids away from electrical equipment.
- Unplug connectors by pulling on the plug and not the cord.
- Use fuses where appropriate.
- Ensure all equipment is properly grounded.
- Provide support to wires to prevent stress on terminals.

To ensure proper and safe operation, caution must be taken at the installation site to make sure it is free from excessive moisture, fluctuating temperature, dust and corrosive materials. Choose a mounting surface with the least amount of vibration and not more than **0.125" (3.175mm)** thick.

- 1) Choose a suitable mounting location based on the criteria above.
- 2) Create a rectangular cutout in the panel that is minimum 3.9" (99mm) high and 6.2" (158mm) wide.
- 3) Place the controller into the panel cutout so that the LCD screen and buttons are facing out.
- 4) Place the mounting clips into the designated slots on the top and bottom of the controller.
- 5) Tighten the screws on the clips until the controller is snug against the panel. Do not over tighten, the bottom of the screws should angle very slightly away from the controller.
- 6) If applicable, snap the RelayPak (RP100) to the back of the controller. Place one side of the RP100's tabs into the slot on the back of the controller and, without pushing on the relays, snap the other tab into place.





## 2.1 General Wiring Notes

The following important wiring guidelines should be followed:

1. Use a minimum of 18AWG wire for all connections.
2. Battery + and Battery - connections on the controller should be run directly to the positive and negative terminals on the battery to prevent voltage drops from negatively impacting the controller.
3. Limit the wire length to 20ft (6.1m) to any I/O on the controller (e.g. Switched Input, Switched Outputs, AC Sensing, and Analog Inputs).

The TOUGH Series contains a TVS to protect the I/O and internals from a transient on the main battery (the battery the controller is powered from). If you have I/O connected to other batteries or power supplies those I/O must contain their own voltage transient protection. Otherwise the I/O and/or controller can be damaged if the transient exceeds the maximum rated voltage of the I/O. A device that provides this kind of protection is known as a TVS or a varistor.

4. The switched outputs already contain a kickback diode. Do not connect relays with an internal kickback diode to a switched output as the output may be shorted. This includes relays in the relaypak.
5. Fusing
  - a. A fuse should be placed inline with the battery + wire going to the controller power. A 10A fuse is suggested.
  - b. The AC Voltage A, B, and C lines should be fused near the source of AC voltage with a 1A fuse to protect personnel if any of these lines become disconnected or damaged.
  - c. If using the RelayPak the power going to the relay commons should be fused.
6. For noisy environments some guidelines are:
  - a. Replace speed sensing wire with twisted pair from the sensor to the controller.
  - b. Consider using isolated sensors (i.e. two terminal) and use twisted pair wiring to connect from engine to controller.

The following enclosure guidelines should be followed:

1. It is recommended to use vibration mounts.
2. For outdoor applications, it is recommended to use a sealed enclosure.

## 2.2 Terminal Descriptions

### Main Connector (J4)

Terminal	Name	Description
J4-1	+Battery	Provides power to the controller from the battery
J4-2	+Battery	Provides power to the controller from the battery
J4-3	Ground	Provides ground return for the controller
J4-4	Ground	Provides ground return for the controller
J4-5	Switched Input A	Configurable to detect +Battery, Ground, or Open
J4-6	Switched Input B	Configurable to detect +Battery, Ground, or Open
J4-7	Switched Input C	Configurable to detect +Battery, Ground, or Open
J4-8	Switched Output A	Outputs +Battery voltage when active (Max Current: 1A)
J4-9	Switched Output C	Outputs +Battery voltage when active (Max Current: 1A)
J4-10	Switched Output B	Outputs +Battery voltage when active (Max Current: 1A)
J4-11	Sensor Ground	Provides ground return for 2-wire (isolated) sensors
J4-12	Sensor Input A	High impedance sensor input (0 - 7,500Ohm)
J4-13	Sensor Input B	Low impedance sensor input (0 - 750Ohm)
J4-14	Sensor Input C	Universal sensor input (0 - 750Ohm, 0 - 7,500Ohm, 0 - 5 VDC, 4 - 20mA). See <a href="#">Universal Sensor</a> section for more information.

### Expansion Connector (J3)

Terminal	Name	Description
J3-1	Switched Input D	Configurable to detect +Battery, Ground, or Open
J3-2	Switched Input E	Configurable to detect +Battery, Ground, or Open
J3-3	Switched Output D	Outputs +Battery voltage when active (Max Current: 1A)
J3-4	Switched Output E	Outputs +Battery voltage when active (Max Current: 1A)
J3-5	Switched Output F	Outputs +Battery voltage when active (Max Current: 1A)
J3-6	Sensor 5V	Provides 5 VDC for electronics sensors.
J3-7	Sensor Ground	Provides ground return for 2-wire sensors
J3-8	Sensor Input D	Universal sensor input (0 - 750Ohm, 0 - 7,500Ohm, 0 - 5 VDC, 4 - 20mA) See <a href="#">Universal Sensor</a> section for more information.

**Communications Connector (J6)**

Terminal	Name	Description
J6-1	RS485 + (Non-Inverting)	Non-Inverting communications line for Modbus (RS485). This is also often known as A.
J6-2	RS485 - (Inverting)	Inverting communications line for Modbus (RS485). This is also often known as B.
J6-3	No Connection	No Connection
J6-4	CAN-H	Communications line for CAN Bus (J1939)
J6-5	CAN-L	
J6-6	CAN-Shield	Connect the shield of the twisted pair cable to this terminal
J6-7	Speed Sensing A	Connect to a magnetic pickup, tachometer, or a flywheel alternator. Not polarity sensitive and not required if using AC voltage terminals for speed sensing.
J6-8	Speed Sensing B	Connect to a magnetic pickup, tachometer, or a flywheel alternator. Not polarity sensitive and not required if using AC voltage terminals for speed sensing.
J6-9	No Connection	No Connection
J6-10	RS485-Common	Common line for Modbus (RS485)

**Generator AC Voltage (J7)**

Terminal	Name	Description
J7-1	Phase A	Connect to Phase A of the generator
J7-2	Phase B	Connect to Phase B of the generator
J7-3	Phase C	Connect to Phase C of the generator
J7-4	Neutral	Connect to neutral.

**Generator AC Current (J5)**

Terminal	Name	Description
J5-1	Phase A	Connect to current transformer for Phase A of the generator
J5-2	Phase B	Connect to current transformer for Phase B of the generator
J5-3	Phase C	Connect to current transformer for Phase C of the generator
J5-4	CT Common	Connect to the commons of the current transformers

## 2.3 Wiring Harnesses

Terminal	Color	Wire Text	Description
J6-1			Not Populated
J6-2			Not Populated
J6-3			Not Populated
J6-4	White	CAN HIGH	CAN/J1939 High
J6-5	White	CAN LOW	CAN/J1939 Low
J6-6	White	CAN GND	CAN/J1939 Shield
J6-7	Green	SPEED INPUT	Speed Input
J6-8	Green	SPEED REF	Speed Reference
J6-9			Not Populated
J6-10			Not Populated


Terminal	Color	Wire Text	Description
J6-1	Blue	RS485 A	Modbus A (+)
J6-2	Blue	RS485 B	Modbus B (-)
J6-3			Not Populated
J6-4	Black	CAN HIGH	CAN/J1939 High
J6-5	Black	CAN LOW	CAN/J1939 Low
J6-6	Black	CAN GND	CAN/J1939 Shield
J6-7	Green	SPEED INPUT	Speed Input
J6-8	Green	SPEED REF	Speed Reference
J6-9			Not Populated
J6-10	Blue	RS485 GND	RS485 Common

Terminal	Color	Wire Text	Description
J7-1	Orange	PHASE A	Generator Voltage
J7-2	Orange	PHASE B	
J7-3	Orange	PHASE C	
J7-4	Orange	NEUTRAL	

Terminal	Color	Wire Text	Description
J5-1	Red	PHASE A	Gen. Current (A)
J5-2	Red	PHASE B	Gen. Current (B)
J5-3	Red	PHASE C	Gen. Current (C)
J5-4	Red	CT COMMON	CT Common


Terminal	Color	Wire Text	Description
J4-1	Red	BATT POS	Battery Positive
J4-2			Not Populated
J4-3	Black	BATT NEG	Battery Negative
J4-4	Black	BATT NEG	Relay/Pak Coil -
J4-5	Tan	SW IN A	Switched Input A
J4-6	Tan	SW IN B	Switched Input B
J4-7	Tan	SW IN C	Switched Input C
J4-8	Purple	SW OUT A Fuel	Relay/Pak relay A
J4-9	Purple	SW OUT C Crank	Relay/Pak relay C
J4-10	Purple	SW OUT B	Relay/Pak relay B
J4-11	Brown	SEN GND	Sensor Ground
J4-12	Brown	SEN IN A	Sensor Input A
J4-13	Brown	SEN IN B	Sensor Input B
J4-14	Brown	SEN IN C	Sensor Input C

Terminal	Color	Wire Text	Description
J4-1	Red	BATT POS	Battery Positive
J4-2			Not Populated
J4-3	Black	BATT NEG	Battery Negative
J4-4			Not Populated
J4-5	Tan	SW IN A	Switched Input A
J4-6	Tan	SW IN B	Switched Input B
J4-7	Tan	SW IN C	Switched Input C
J4-8	Purple	SW OUT A	Switched Output A
J4-9	Purple	SW OUT C	Switched Output C
J4-10	Purple	SW OUT B	Switched Output B
J4-11	Brown	SEN GND	Sensor Ground
J4-12	Brown	SEN IN A	Sensor Input A
J4-13	Brown	SEN IN B	Sensor Input B
J4-14	Brown	SEN IN C	Sensor Input C



Terminal	Manufacturer	Housing P/N	Crimps P/N
J3	Molex	39-01-2060	39-00-0039
J4	Molex	39-01-2140	39-00-0039
J5/J7 - AC Voltage	Tyco	1-480702-0	350536-1
J5 - AC Current	Tyco	1-480702-0	350216-1
J6	Molex	39-01-2100	39-00-0039
Relay/Pak J1	Molex	39-01-2060	39-00-0039

Terminal	Color	Wire Text	Description
J3-1	Tan	SW IN D	Switched Input D
J3-2	Tan	SW IN E	Switched Input E
J3-3	Purple	SW OUT D	Switched Output D
J3-4	Purple	SW OUT E	Switched Output E
J3-5	Purple	SW OUT F	Switched Output F
J3-6			Not Populated
J3-7	Brown	SEN GND	Sensor Ground
J3-8	Brown	SEN IN D	Sensor Input D



Terminal	Color	Wire Text	Description
J5-1	Orange	PHASE A	Generator Voltage
J5-2	Orange	PHASE B	
J5-3	Orange	PHASE C	
J5-4	Orange	NEUTRAL	

Notes:  
(1) Harnesses are 5 feet in length except for the three DWG1522 RS485 wires which are 6 inches in length.

Terminal J3-3 is left unpopulated from the factory and can be populated using one of the two individual wires that came with the harness (a short one with two crimps on both sides and a long one with a crimp on one side and a pigtail on the other). If using relay D on the Relay/Pak insert one end of the short wire into J3-3 and the other end into Relay/Pak J1-1. If you are not using the relay pack insert the longer wire into J3-3.

Tough Series Harness Guide  
DWG-1547R2.0

**Speed Sensing:**

- (1) Input is to be used for a magnetic pickup (MPU) sensor, alternator, or tach output.
- (2) Not required if using AC Voltage for speed sensing.
- (3) The polarity of the input does not matter.
- (4) Use a shielded cable. Leave one side of shield unterminated.
- (5) If using a MPU:
  - (a) A shielded MPU is recommended.
  - (b) One side of the mag pickup also has to be connected to ground in addition to the controller.

**CAN (TE350/TE410) and RS485 (TE410):**


- (1) A 120 Ohm impedance twisted pair cable is required:
  - (a) Examples are Belden 15641 (single twisted pair) and Belden 7895A (two twisted pair).
- (2) RS485 requires a termination resistor.
- (3) To prevent noise affecting controller operations bind the shielded cable within at least 6 inches of the terminal. Closest to 3 inches is better.
- (4) Terminate the bus on each end with a 120 Ohm resistor.
- (5) Ground the shield on one end. Leave the other end unconnected.

**AC Current (CT's):** If current readings are unstable try connecting the CT Common wire to ground. Ensure the connecting wire is as short as possible.

**Sensors:** For hardware revisions below 2.0 if using non-isolated (one-wire) sensors connect sensor common to battery negative. Make connection at the same point the main ground connection is made.

**Switched Inputs:** For runs longer than 20 feet or in noisy environments place a relay in circuit close to controller to prevent false triggering due to noise. See the autostart example in this drawing.

**Switched Outputs:** Relay drivers. When using to trigger logic a 2.2K Ohm, 1 W resistor is required to be installed from output to ground to ensure the output goes to 0 VDC in off state.



**Relay/Pak (RP-100) Schematic Representation**

Speed Sensing (Max 50V/AC)

10A Fuse

BAT (12VDC)

Emergency Stop

Ground

Switch Input A

Switch Output A

Switch Output B

Switch Output C

Switch Output D

Relay A (1.0K-42)

Relay B (4.0K-50)

Relay C (2.0K-43)

Relay D (5.0K-46)

RP-1-6

RP-1-4

RP-1-1

RP-1-2

RP-1-3

RP-1-5

RP-1-7

RP-1-8

RP-1-9

RP-1-10

RP-1-11

RP-1-12

RP-1-13

RP-1-14

RP-1-15

RP-1-16

RP-1-17

RP-1-18

RP-1-19

RP-1-20

RP-1-21

RP-1-22

RP-1-23

RP-1-24

RP-1-25

RP-1-26

RP-1-27

RP-1-28

RP-1-29

RP-1-30

RP-1-31

RP-1-32

RP-1-33

RP-1-34

RP-1-35

RP-1-36

RP-1-37

RP-1-38

RP-1-39

RP-1-40

RP-1-41

RP-1-42

RP-1-43

RP-1-44

RP-1-45

RP-1-46

RP-1-47

RP-1-48

RP-1-49

RP-1-50

RP-1-51

RP-1-52

RP-1-53

RP-1-54

RP-1-55

RP-1-56

RP-1-57

RP-1-58

RP-1-59

RP-1-60

RP-1-61

RP-1-62

RP-1-63

RP-1-64

RP-1-65

RP-1-66

RP-1-67

RP-1-68

RP-1-69

RP-1-70

RP-1-71

RP-1-72

RP-1-73

RP-1-74

RP-1-75

RP-1-76

RP-1-77

RP-1-78

RP-1-79

RP-1-80

RP-1-81

RP-1-82

RP-1-83

RP-1-84

RP-1-85

RP-1-86

RP-1-87

RP-1-88

RP-1-89

RP-1-90

RP-1-91

RP-1-92

RP-1-93

RP-1-94

RP-1-95

RP-1-96

RP-1-97

RP-1-98

RP-1-99

RP-1-100

Relay A N.O. Contact

Relay B N.O. Contact

Relay C N.O. Contact

Relay D N.O. Contact

Crack

Engine Temperature

Oil Pressure

Glowplug

Breaker (Speed appropriately)

Speed Sensor

Fuel

Emergency Stop

Battery (5.5-36V)

10A Fuse

Switch Input A

Switch Output A

Switch Output B

Switch Output C

Switch Output D

Relay A (1.0K-42)

Relay B (4.0K-50)

Relay C (2.0K-43)

Relay D (5.0K-46)

RP-1-6

RP-1-4

RP-1-1

RP-1-2

RP-1-3

RP-1-5

RP-1-7

RP-1-8

RP-1-9

RP-1-10

RP-1-11

RP-1-12

RP-1-13

RP-1-14

RP-1-15

RP-1-16

RP-1-17

RP-1-18

RP-1-19

RP-1-20

RP-1-21

RP-1-22

RP-1-23

RP-1-24

RP-1-25

RP-1-26

RP-1-27

RP-1-28

RP-1-29

RP-1-30

RP-1-31

RP-1-32

RP-1-33

RP-1-34

RP-1-35

RP-1-36

RP-1-37

RP-1-38

RP-1-39

RP-1-40

RP-1-41

RP-1-42

RP-1-43

RP-1-44

RP-1-45

RP-1-46

RP-1-47

RP-1-48

RP-1-49

RP-1-50

RP-1-51

RP-1-52

RP-1-53

RP-1-54

RP-1-55

RP-1-56

RP-1-57

RP-1-58

RP-1-59

RP-1-60

RP-1-61

RP-1-62

RP-1-63

RP-1-64

RP-1-65

RP-1-66

RP-1-67

RP-1-68

RP-1-69

RP-1-70

RP-1-71

RP-1-72

RP-1-73

RP-1-74

RP-1-75

RP-1-76

RP-1-77

RP-1-78

RP-1-79

RP-1-80

RP-1-81

RP-1-82

RP-1-83

RP-1-84

RP-1-85

RP-1-86

RP-1-87

RP-1-88

RP-1-89

RP-1-90

RP-1-91

RP-1-92

RP-1-93

RP-1-94

RP-1-95

RP-1-96

RP-1-97

RP-1-98

RP-1-99

RP-1-100

Relay A N.O. Contact

Relay B N.O. Contact

Relay C N.O. Contact

Relay D N.O. Contact

Crack

Engine Temperature

Oil Pressure

Glowplug

Breaker (Speed appropriately)

Speed Sensor

Fuel

Emergency Stop

Battery (5.5-36V)

10A Fuse

Switch Input A

Switch Output A

Switch Output B

Switch Output C

Switch Output D

Relay A (1.0K-42)

Relay B (4.0K-50)

Relay C (2.0K-43)

Relay D (5.0K-46)

RP-1-6

RP-1-4

RP-1-1

RP-1-2

RP-1-3

RP-1-5

RP-1-7

RP-1-8

RP-1-9

RP-1-10

RP-1-11

RP-1-12

RP-1-13

RP-1-14

RP-1-15

RP-1-16

RP-1-17


RP-1-18

RP-1-19

RP-1-20

RP-1-21

RP-1-22




## 2.6 Wiring Considerations

The following sections are meant to describe certain wiring configurations and are for illustrative purposes only. Not all applications are the same. Please ensure you modify these examples to fit your unique system requirements.

### 2.6.1 Remote Start Contact (Start/Stop)

As of Firmware version 1.60 the start/stop is factory defaulted to switch input B (changeable) and the trigger factory defaulted to Close +BAT. For older firmware versions you must set Start/Stop to Switched Input B or as desired and set the trigger mode to Close +BAT. The trigger can be set to any of four options but Close +BAT gives the best immunity to noise.


For runs over 20ft (6.1m) especially in noisy environments DYNAGEN recommends connecting the Start/Stop to an external relay. The relay needs to be located as close to the controller as possible.



### 2.6.2 Emergency Stop Wiring

If Emergency Stop functionality is required, it is mandatory to install an external mushroom style switch wired in series with the fuel or ignition supply to ensure reliable and immediate shutdown upon activation.

Shown below is an example wiring diagram of a double pull, single throw switch being used to activate the e-stop input and cut power to the fuel solenoid. In this configuration, the e-stop is activated when there is an open circuit to the switched input and inactive when the input detects +Battery voltage.



### 2.6.3 Universal Sensor


Universal Sensors have the ability to be configured to detect different sender types (0 - 750Ohm, 0 - 7,500Ohm, 0 - 5 VDC, 4 - 20mA). The examples shown below are advanced applications of the universal sensor.



**NOTE:** Custom Sensor tables are required for the universal sender to work with these examples. See the [Custom Sender Table](#) section for more information.

**Example #1:** The following example shows the correct way for wiring a 4-20mA sensor. The 240Ohm resistor is required to transform the 4-20mA current into the 0-5V voltage range required by the controller.

**4-20mA Wiring Example**



**Example #2:** Sometimes it is required to measure voltages outside the 0-5V range allowed by the controller. To do this you must use a voltage divider with appropriate scaling resistors. The equation to calculate the resistor values is as follows:

$$V_{out} = \left( \frac{R1}{R1 + R2} \right) \times V_{in}$$

$V_{out} = 5V$


$V_{in}$  = Maximum Voltage to Read

$R1$  = Common Resistor Value > 10kOhm

$R2$  = Calculated Resistor Value (Select closest common resistor value)

The following diagram shows the typical wiring of a voltage divider. The resistors' values have been selected to allow the controller to read up to 36V from an external battery bank.

**0-36V Wiring Example**



**NOTE:** A TVS (i.e. varistor) is required if the battery is different than the battery the controller is powered from. The controller's TVS cannot protect the sensor input from transients in this case.




### 2.6.4 CAN Bus Wiring (J1939)

The following table outlines some items that must be taken into consideration when connecting to a CAN bus engine.

Consideration	Description
Bus Termination	Each end of the bus must be terminated from CAN H to CAN L with 120Ohm +/- 10 Ohm resistors. The resistor must be able to handle at least 400mW of power dissipation.
Cable Selection	<p>A twisted pair 120Ohm impedance cable is required for communications. For better protection a shielded twisted pair cable is recommended.</p> <p>Examples are:</p> <ol style="list-style-type: none"> <li>1. Belden 9841 - Shielded cable with one twisted pair, 24AWG</li> <li>2. Belden 7895A - Shielded cable with two twisted pair, 20AWG</li> </ol> <p>For short runs of 5 feet or less regular 18AWG wiring can often be run.</p>
Shielding	If using a shielded cable the shield must be connected to ground on one end of the bus only. This prevents loss of data from electromagnetic interference.
Termination at the Controller	The twisted pair cable must terminate no farther than 6 inches from the controller's CAN (J1939) connector. Three inches is ideal.


#### Communications Wiring



It is common practice to use the fuel output to trigger the ECM key input to enable the ECM before cranking. For some ECMs to function, they must be powered/enabled for a certain period before cranking to allow time for the ECM to boot up. There are two ways to provide this time:

- Set a preheat time or increase the preheat time to allow longer time for the ECM to boot up before cranking. The fuel output turns on at the start of preheat.
- Enable the Auto Power ECM setting in the Communications -> CAN Bus (J1939) menu will cause the fuel output to turn on in Auto mode and stay on.

#### ECM Wiring



### 2.6.5 Modbus Wiring

The following table outlines some items that must be taken into consideration when connecting up a Modbus system.

Consideration	Description
Bus Termination	Each end of the bus must be terminated from A to B with 120Ohm +/- 10 Ohm resistors. The resistor must be able to handle at least 400mW of power dissipation.
Cable Selection	<p>Shielded twisted pair 120Ohm impedance cable is required for communications. Shield drain wire is NOT be used for the RS485 common. The cable must have one twisted pair for A and B and a seperate wire or twisted pair for common.</p> <p>An example is Belden 7895A, a two twisted pair, 20AWG, where the second pair can be used for the RS485 common.</p>
Distance (Power and Ground)	<p>If running power and ground from the battery of your system to a remote device, use the following guidelines for the gauge of the power and ground wires.</p> <ol style="list-style-type: none"><li>1. Up to 450ft (137.2m) - 22AWG</li><li>2. Up to 700ft (213.4m) - 20AWG</li><li>3. Up to 1125ft (342.9m) - 18AWG</li><li>4. Up to 1800ft (548.6m) - 16AWG</li><li>5. Up to 2800ft (853.4m) - 14AWG</li></ol>
Termination at the Controller	The above cable must terminate no farther than 6 inches from the controller's RS485 (Modbus) connector. Three inches is ideal.

Refer to the Example wiring diagram for a wiring example.


## 2.6.6 Current Transformers

When wiring current transformers into the system you must follow these considerations:

1. The maximum amperage allowed on the secondary is 5A. A 5:X ratio CT should be used where X is the maximum primary amperage rating (e.g. 200A).
2. The CT power rating should be a minimum of 1VA.
3. The controller CT burden is 0.02Ohms (0.5 VA).
4. The current transformer of each phase must be facing the same direction. See below.
5. The CT Common connection must be connected to the black wire on each current transformer.
6. The wires from the current transformers to the controller should be as short as possible.
7. The CT wires should be run in a separate conduit from the AC voltage wires.



**NOTE:** If readings are unstable with the configuration shown below, attempt connecting the CT Common's black wire to the negative terminal of the battery. Ensure the connecting wire is as short as possible.






### 2.6.7 RelayPak (Optional)

**Model Number: RP100-VM**

The RelayPak is used to provide up to four built-in slave relays in a compact and easy to wire package. This allows the low current outputs of the controller to switch on high current relays on the RelayPak.


Note: The relayPak can be used to sense DC voltages up to 39 VDC using one of the Auxiliary Sensor Inputs on the controller. The VM in RP100-VM refers to this voltage sensing capability. Refer to drawing DWG1552 under [www.dynagen.ca/support](http://www.dynagen.ca/support). If this capability is used, the forth relay, Relay D, cannot be used.

#### Electrical Specifications


Specification	Rating
Operating Voltage	12V / 24V
Output Pilot Duty Rating	5.83A Per Relay @ 12V
Output Resistive Rating	10A Continuous Per Relay @ 12V 40A Momentary Per Relay @ 12V
Relay Style	Automotive Cube
Standards	 UL 6200 recognized component. Consult factory for UL conditions of acceptability.



**WARNING:** You must use relays in the RelayPak that are suitable for the system voltage. Example: 12V relays in a 12V system and 24V relays in a 24V system.



Schematic Representation



### 2.6.8 J6 Speed Inputs

If the application is a generator the speed inputs on connector J6 are optional as the AC Voltage sensing inputs can be used to sense speed via the frequency.

The speed inputs are rated to a maximum of 50VAC.

#### Magnetic Pickup Sensor

The following must be followed:

- (1) The sensor must be of a shielded type.
- (2) A twisted pair shielded cable must be used for the connection.
- (3) The shield must be connected to ground on one side only.
- (4) One side of the sensor must be grounded in addition to connecting to the controller. Not grounding one side of the sensor can cause erratic behavior.

Requirements 1 to 3 can be ignored at the customer's own risk but item 4 must be followed otherwise unreliable operation may result.

The polarity of the speed inputs does not matter.

#### Other Speed Signal Sources

Other speed sources such as from an alternator or tachometer can be used but note that these are often very noisy and must be filtered before connecting to the speed inputs. Filtering means must be provided by the installer if required. Installer must determine suitability for their application. Dynagen does not provide any means of filtering and cannot guarantee compatibility.

## 3 Pumping Applications

The TE Series of controllers are designed specifically with pumping applications in mind. The TE Series is capable of manual and automatic speed control.

- Manual - Manually adjusting the engine speed.
- Automatic - Automatically starting the engine, ramping up to a desired (goal) speed, and optionally controlling the engine speed to obtain a desired objective. An example of a desired objective is to maintain a certain flow rate in or out of a tank.

The next sections will cover these two options.

### 3.1 Manual Speed Control

Manual speed control allows the user to adjust the speed manually using the front panel UP (speed increment) and DOWN (speed decrement) buttons or via the speed increment / speed decrement switched inputs.

How to Enable:

- Manual speed control is enabled on a manual run.
- A manual run is triggered by starting the controller:
  - using the RUN button on the front face
  - using the "key switch" switched input function
- Manual speed control is disabled if:
  - the controller is running in automatic speed control. Pressing the Run button while in cool down mode will not trigger manual speed control. The controller must be in the OFF or AUTO mode.
  - a long time run is active (see Timers > Schedulers > [Long Time Run](#))


By using the "Run Button" setting under the Other Config > Pump System menu the user can:

- either adjust speed once idle mode has been reached, or,
- adjust speed after the engine has finished ramping up to the rated speed.

The amount that the speed increments/decrements is determined by the Bump Speed setting under the Other Config > Ramp Setting menu. For every second the increment/decrement means is active the engine speed will be increment/decrement by the bump speed.

If the Bump Speed setting is disabled then the speed will increase by 1 RPM/s with each button push and will increase to 10 RPM/s, 50 RPM/s, and 100 RPM/s each second until 100 RPM/s is obtained if the button is held down.





## 3.2 Automatic Speed Control

Automatic speed control is triggered by an auto start condition. Auto start conditions include the remote start/stop, auxiliary sensor inputs, and floats. Pressing the RUN button on the front face of the controller or triggering the Key switched input do not trigger the automatic speed control; see the manual speed control above for those two cases.


Once an auto start has been initiated the engine will go through the ramp sequence until it reaches the goal speed. Once the goal speed has been reached the engine will remain at that speed unless process control is enabled. If process control is enabled, process control will take over once the engine has ramped up to the goal speed.

### 3.2.1 Autostarting on Floats


Single or dual floats can be used as means to auto start and stop the engine based on a level of a tank. The below figures indicate how the engine responds to the floats.

If single float is used then only one of the Float 1 or Float 2 switch input function need to be enabled. If both float switched inputs functions are enabled then float 1 is used.

The float auto start means must be enabled by setting the Float Autostart setting under the Application > Function menu to Single or Dual. When "Float Autostart" is enabled a graphic indicating the positions of the floats is shown in a special page during RUN mode. This special page also indicates the current engine speed and optionally the tank level.




The Auxiliary Sensor 5 (Transducer) feature under the Application menu can be used as a safety shutdown or warning means in case of a float failure. The below figure demonstrates this functionality. In addition if the Transducer display setting is enabled a tank display graphic will be shown adjacent to the float indicators indicating the fill level of the tank.



3.2.2 Ramp up and Intermediate Speed

Once an auto start is initiated the engine will go through a ramp up in speed until it reaches the goal speed. This is indicated in the below chart. Refer to the Other Config > Pump System menu for settings indicated in the below chart. The Warm-up and Cooldown times can be found in the Timers > Engine Logic menu.



### 3.2.3 Process Control using Engine Speed

The process control feature is supported in the TE series firmware version 1.91 and above.

Process Control (aka closed loop control) is a programmable option that can take over once the goal speed is reached after intermediate. Process control uses the engine speed to control a process variable which is sensed by one of the auxiliary sensor inputs: Auxiliary Sensor 1 to 4 or Transducer(Aux 5 in RapidCore).

The settings for process control are located under Other Config > [Process Control](#) in the front panel menu or Pumping Applications > Closed Loop Control in RapidCore. See the [Process Control](#) section (Settings > Other Config > Process Control) for more information.

## 3.3 Speed Limiting


There are three settings that control the absolute or change in speed for all speed control features. These settings can be used to prevent engine damage and/or provide a safety means for equipment users.

- The TSC1 RPM/s setting under Sensors > Engine Speed > RPM Control limits the rate of change in engine speed.
- The Min Speed and Max Speed settings under Other Config > Pump System limit the minimum and maximum engine speed respectively.

## 3.4 Electronic Engines

On newer engines, the TE350/TE410 usually controls engine speed by sending the J1939 TSC1 protocol over the CANbus to the electronic engine control module (ECM). The ECM is responsible for governing the engine, controlling emissions and providing engine protection. The following figure shows typically how these electronic engines are wired.

- Power / Ground - The ECM usually must be powered directly from the battery terminals.
- Keyswitch Input (Ignition Input) - There is usually an input on the ECM that wakes the ECM and tells it a start (crank cycle) is about to begin. The ECM then begins to monitor engine speed for start detection.
- Start SW Input - The input to indicate to crank or start the engine.
- CAN High / CAN Low (CAN-H, CAN-L) - The J1939 protocol bus that the ECM and TE350/TE410 use to communicate with one another. TSC1 (J1939 speed command) is sent over this bus as well as engine temperature, oil pressure, and other parameters.




TE Series ECM Example  
DWG-1556 R1.0

## 4 Using the Controller

The LCD display is the primary source of information from the controller. It allows you to view/change settings and monitor the status of sensors and other engine peripherals.

LCD Display



### Using the Menu System

Task	Description
Entering Menu	When in the OFF mode, press the enter button to bring up the menu.
Navigating Menu	Once in the menu, use the up and down arrows to navigate. Pressing enter will move you into that menu.
Change a Setting	Scroll to the desired value and press enter to select. A check mark should appear beside that item. Press enter again to save the setting and return to the previous screen.
Scroll Parameters	When in Auto or Running mode, pressing the up and down arrows will scroll through the parameter pages.
Lock Screen	When in Auto or Running mode, the screen can be locked to a certain parameter page by pressing Auto and unlocked by pressing Auto again.
Events History	Once in the menu, select Events History to view the most recent controller event. Use the up and down arrows to navigate to other events. The controller can store up to 150 events. If more than 150 events occur, the oldest event is deleted to make room for the next event.

### Front Panel Items

Item	Name	Description
	Off Button	Used for turning off the engine or exiting out of Auto mode. This is not intended to function as an Emergency Stop as there are conditions in which it will not shut down the engine. See the <a href="#">OFF Button Function</a> section for more information.
	Auto Button	Used for placing the controller into AUTO mode or locking the LCD screen when viewing parameters. Once in AUTO mode, the controller waits for a start command to be received.
	Run Button	Used to start the engine manually. The Off button must be used to shut down the engine if it has been started using the front panel.
	Up/Speed Increment Button	Used for moving around in the menu, changing a setting's value, or incrementing the engine speed in manual mode.
	Scroll/Enter Button	Used for entering the menu system, accepting settings, or changing the currently displayed parameter page.
	Down/Speed Decrement Button	Used for moving around in the menu, changing a setting's value, or decrementing the engine speed in manual mode.
	Generator/Engine LED	Green = Engine running with no issues Amber = Engine running with warnings Red = Engine shut down on failure

## 4.1 Modes, Starting and Stopping

The following table describes the different operating modes of the controller:

### Modes

Mode / State	Description
OFF	When in the OFF mode, the engine cannot be remotely started.
Auto	When in the Auto mode, the engine waits to receive a start command.
Running	When engine is Running, the controller monitors engine parameters and waits to receive a stop command.
Failure	When a failure occurs, the controller shuts down the engine and displays the reason for failure. The unit must be reset using the front panel OFF button with the exception of Modbus.
Menu	When in the menu mode, settings can be changed and the events history may be viewed.

The following table describes the different methods for starting a controller. Unless using the Manual Run method to start the controller, the controller must be in AUTO mode.

### Starting Methods

Methods	Description
Manual Run	Pressing the Run button will start the engine. You must press the OFF button to shut down the engine.
Keyswitch Start	Manual start via the key switch switched input. A switched input must be set to keyswitch function.
<a href="#">Start / Stop Switched Input</a>	When this input is active the engine will start. When the input becomes inactive the engine will shut down.
<a href="#">Momentary Switched Inputs</a>	Switched inputs Momentary Start and Momentary Stop can be used for starting and stopping of the engine. Unlike other inputs, they only have to be activated for a short period of time.
<a href="#">Battery Recharge</a>	When the battery voltage drops below a certain level the engine will start and run for a predetermined amount of time.
<a href="#">Exerciser</a>	When the scheduled exerciser interval occurs the engine will start and run for a predetermined amount of time.
<a href="#">Weekly Scheduler</a>	When a scheduled event occurs the engine will start and run for the programed amount of time.
<a href="#">Auxiliary Sensors</a>	When a properly configured Auxiliary sensor falls below / rises above a certain point the engine will start as determined by the Auxiliary Sensors -> Mode Select settings.
<a href="#">Modbus Start</a>	When a certain command is sent to the controller over Modbus the engine will start. See the Modbus Reference Manual for more information.
J1939 Start	Start/stop command send over the J1939 CANbus. For example from the TR100 or a remote telemetry device. The controller will display either "J1939 Run" or "J1939 Remote" as the reason for starting.
Float Auto Start	Start triggered by the float 1 or float 2 switched inputs.
ECM Power On	This is not a starting mode like the others. In AUTO mode if the Auto button is held for 3s the fuel output is turned on for 1 hour. "ECM Power On" will be displayed on the screen. Pressing and holding again within the hour will refresh for another hour. This feature can be used to turn on or activate equipment powered by the fuel output. Often this is used by a tech to power the ECM on an electronic engine so a diagnostic tool can obtain information from the ECM.



**WARNING:** See the [Using Cooldown Mode](#) section for more information on how it affects starting and stopping.

### 4.1.1 Starting / Cranking Behavior

Crank disconnect is only monitored at the beginning of cranking. If the engine is already running the starter motor (output set to Crank) may turn on briefly.


If the controller is programmed to use CAN J1939 or a magnetic pickup (sensor or alternator output) the controller will also monitor AC Voltage Phase A line for frequency as a backup or secondary means of crank disconnect. This occurs even if AC Voltage sensing is disabled in the settings.

The oil pressure is not used as a means of crank disconnect.

## 4.2 Speed Control Page

The speed control page is the default page that is shown when the controller is running (RUN mode). It is also displayed in AUTO mode. Scrolling to other pages can be done using the Enter button. After 30 seconds of button inactivity the controller will revert back to the speed control page.

The speed control page displays the engine speed, the float tank (if float auto start is enabled), and the tank level (if Transducer under the Application menu is enabled and Transducer Display is enabled).



## 4.3 Four Parameter Display Pages

There are two special pages that can display four parameters each. These two pages must be setup used the RapidCore Configuration Software.

The choices of parameters are:


- Blank (no parameter displayed for that line)
- Engine Speed
- Battery



- AC Frequency
- Current Run Time
- Engine Hours
- Oil Pressure
- Fuel Level
- Engine Coolant Temperature

If all four lines in a page are set to Blank then the page is not displayed. If two adjacent rows are set to blank the rest of the 3 pairs of rows move up into the two blank rows' area. This means there cannot be more than one blank line in a row.

Parameters can be place on more than one line.



## 4.4 DM1 Page

The DM1 special page is used to display diagnostic trouble codes (DTCs) from an electronic engine module (ECM). If the engine broadcasts a DTC then the DM1 page will appear for 5s or until the user scrolls away. It will disappear and will reappear 50 seconds later if the DTC is active.

The controller LED indicator will also turn amber to indicate a warning condition.


## 4.5 Using Cooldown Mode

When the controller is configured to have a cooldown period (See [Engine Logic](#) section) for the engine, there is some special functionality that must be considered.

The cooldown period is special in that during this time, it will accept a Start Command. This means if the engine is cooling down and a start command is received, the controller will be placed back into a running mode and will not shut down.

**Example:** The following is an example of how the cooldown functionality works.

1. Remote Start contacts close
2. Engine starts and is in the running mode
3. Remote Start contacts open
4. Engine starts cooldown period
5. User presses RUN button on the front panel
6. Engine moves back into running mode and does not shut down
7. Engine can now only be shut down by using the OFF button or Emergency Stop input



## 4.6 Warnings

Warnings are conditions that alert the user to possible issues. These get enabled/disabled when you enable/disable various settings in the controller.

Notable warnings are given in the below table.

Warning Name	Enabled Condition(s)	Description
High Fuel Level	High Fuel Level not disabled (in Sensors > Fuel Level menu).	High Fuel Level warning. This is often used to indicate an over fueling condition where fuel could be overflowing from the fuel tank.
Low Engine Temp	Low Engine Temp not disabled (in Sensors > Engine Temp. menu).	Low Engine Temperature warning. This is often used to indicate a malfunction of the engine block heater in stationary generator applications.
Low Oil Pressure	Switched input set to "Oil Pres. Warn" function. See <a href="#">Switched Inputs</a> . Triggered if switched input is active during the RUN mode.	Low oil pressure warning.

## 4.7 Failures

Failures are conditions that cause the controller to shutdown to prevent damage to the engine or generator. These get enabled/disabled when you enable/disable various settings in the controller.

Notable failures are given in the below table.

Failure Name	Enabled Condition(s)	Description
ECM Communication Failure	Enabled if loss of ECM communication is enabled. See <a href="#">CAN Bus (J1939)</a> . J1939 feature.	If the controller has not received messages from the ECM for 6s.
Exception*	Always enabled.	Occurs when there is an issue that the controller cannot recover from. For example EMI can cause the microcontroller to become in a bad state or a software bug could cause the code to hang triggering the watchdog. In these cases the controller will reset and enter the failure state.

Failure Name	Enabled Condition(s)	Description
		*The name is configurable so may not match what is here.
Failure To Stop	Disabled when <a href="#">ETS On Duration</a> is set to 0 seconds. Otherwise it is enabled. If used ETS On Duration should be set to at least 2 to 3s otherwise this failure may occur on a normal shutdown.	After ETS countdown is finished if the speed was greater than 50RPM (600RPM for TG350/TG410 firmware 1.88 and greater) for the previous 2s then the controller triggers this failure.
Load Imbalance	See <a href="#">Load Imbalance</a> . AC Current feature.	Generator load imbalance. Excessive AC current on one or more of the three phases.
Low Air Pressure	Switched input set to "Air Pres. Fail" function. See <a href="#">Switched Inputs</a> . Triggered if switched input is active during starting.	Application specific.
Low Coolant Lvl	Switched input set to "Cool. Lvl Fail" function. See <a href="#">Switched Inputs</a> . Triggered if switched input is active.	Low Coolant Level.
Low Hydraulic	Switched input set to "Hyd Pres. Fail" function. See <a href="#">Switched Inputs</a> . Triggered if switched input is active during starting.	Refers to Low Hydraulic pressure usually. Application specific.

If Battle Mode (see Battle Mode in [switched inputs](#)) is active ('Battle Running' is displayed on the screen) the controller will not shutdown on a failure and no failure information will be displayed on the screen. If battle mode is switched off the controller will shutdown on any failure that occurred when battle mode was active.

## 4.8 Event History

The below table lists all events, warnings, and failures than can appear in the controller's event history. The event history is accessed in the menu under "Events History".

Event Name	Event Type	Description
Power On	Event	The controller has powered on.
Auto Enabled	Event	The controller has entered AUTO mode. The controller is waiting for a manual or automatic start condition such as a remote/start stop command.
Off Enabled	Event	The controller has entered OFF mode (Not in Auto displayed on screen). Automatic starting is disabled.
Manual Start	Event	A user has pressed the RUN button on the controller.
Start Cooldown	Event	The controller has entered cooldown. Cooldown has to be enabled under Timers > Engine Logic.
Remote Start	Event	A switched input remote start has been triggered. The controller will start.
Remote Stop	Event	A switched input remote stop has been triggered. The controller will stop.
Emergency Stop	Event	The switched input Emergency Stop has been triggered. The controller has performed an emergency shutdown skipping cooldown.
Start Charging	Event	The controller has auto started because of a low starter battery condition. The low battery restart has to be enabled under Sensors > Battery.
Stop Charging	Event	The controller has ran for the programmed amount of time to recharge the starter battery and is shutting down.
Service Required	Event	The controller requires maintenance. This has to be enabled under Timers > Maintenance. Also after maintenance is performed the tech has to reset the maintenance counter by going to Timers > Maintenance > Reset Counter and selecting "Yes".
Reset Defaults	Event	The controller has loaded default settings. This could have been because the user initiated a factory reset from the RapidCore software or the controller memory has become corrupt. The controller will need to be programmed with the proper settings if applicable.

Service Complete	Event	The tech has performed service on the engine/generator and has reset the maintenance counter as mentioned in "Service Required" above.
Exerciser Bypass	Event	The exerciser, if enabled under Timers > Exerciser, has been skipped. This could happen if the controller was otherwise running or powered off when an exerciser was scheduled to be performed.
Start Exercise	Event	The controller has auto started to perform an exercise.
Stop Exercise	Event	The controller has ran for the programmed exercise and is now shutting down.
Log Cleared	Event	The controller Event History has been cleared either from user action (via the RapidCore software) or because the controller memory was corrupt.
Modbus Start	Event	The controller has auto start from a start command sent to it's RS485 Modbus port.
Modbus Stop	Event	The controller has auto stopped from a stop command sent to it's RS485 Modbus port.
Genset Disable	Event	Applies to the Kubota electronic engine. Level 3 shutdown has occurred.
Engine Started	Event	The engine has successfully started and entered the RUN mode.
J1939 Remote	Event	The controller has auto started due to a command send over it's CAN J1939 port.
Idle Speed	Event	The controller has entered IDLE mode either from the idle switched input, the warmup or cooldown idle feature under Engine Logic or some other reason. Under speed, under frequency, and under voltage warnings and failures are disabled.
Rated Speed	Event	The controller has exited idle mode and has gone back into normal running.
Sensor 1 Run	Event	The controller has auto started due to a auxiliary sensor 1 "start on low" or "start on high" request.
Sensor 2 Run	Event	The controller has auto started due to a auxiliary sensor 2 "start on low" or "start on high" request.
Sensor 1 Stop	Event	The controller has shutdown due to a auxiliary sensor 1 "start on low" or "start on high" stop request.
Sensor 2 Stop	Event	The controller has shutdown due to a auxiliary sensor 2 "start on low" or "start on high" stop request.
Switch Start	Event	A controller start was triggered by the momentary start switched input.
Switch Stop	Event	A controller start was triggered by the momentary start switched input.
Regen Inhibited	Event	Electronic engines with a Diesel Particulate Filter (DPF) only. The user requested that the automatic regeneration of the DPF be disabled.
Force Regen	Event	Electronic engines with a Diesel Particulate Filter (DPF) only. The user requested a manual regeneration of the DPF.
Auto Regen	Event	Electronic engines with a Diesel Particulate Filter (DPF) only. The engine ECM has performed an automatic regeneration of the DPF.
Sensor 3 Run	Event	The controller has auto started due to a auxiliary sensor 3 "start on low" or "start on high" request.
Sensor 4 Run	Event	The controller has auto started due to a auxiliary sensor 4 "start on low" or "start on high" request.
Sensor 3 Stop	Event	The controller has shutdown due to a auxiliary sensor 3 "start on low" or "start on high" stop request.
Sensor 4 Stop	Event	The controller has shutdown due to a auxiliary sensor 4 "start on low" or "start on high" stop request.
Log Time start	Event	A user has started the controller using the RUN button and the long time run feature is enabled under Timers > Long Time Run. The controller will run for the duration specified under "Long Time Run" and then automatically shut down.

Scheduler Start	Event	The controller has auto started due to a daily schedule set up in Timers > Week Scheduler.
Start Canceled	Event	A daily scheduler was canceled either because the controller was not in AUTO mode or start request was ignored. A start request being ignored is an internal error and should not occur.
J1939 Start	Event	Controller started from J1939 using the second J1939 start/stop method. Refer to the J1939 user guide for more information. This is often used by telemetry devices to start/stop the controller.
Key Switch Run	Event	Controller was started by the key switch switched input.
Crank Failed	Warning	The controller has turned it's crank output but has failed to detect the engine is running. After crank rest (if programmed under Timers > Engine Logic) it will try again.
Low Batt InCrank	Warning	During cranking the battery was lower than normal. The level is set under Sensors > Battery.
Charger Fault	Warning	Indicates a battery charger issue. The controller has a battery charger fault switched input. This is used to indicate to the controller the charger has a fault.
High Fuel Level	Warning	The fuel level raised above the high fuel level warning threshold set under Sensors > Fuel Level. Potential over fueling issue.
Under Voltage	Warning	The generator AC voltage has fallen below the under voltage warning setpoint set under AC Monitor > Genset Voltage. Possible issue with the voltage regulator or governing on the engine.
Under Speed	Warning	The generator speed has fallen below the under speed warning setpoint set under Sensors > Engine Speed.
Over Speed	Warning	The generator speed has risen above the over speed warning setpoint set under Sensors > Engine Speed.
High Engine Temp	Warning	The engine temperature has risen above the high engine temperature warning under Sensors > Engine Temp.
Low Oil Pressure	Warning	The oil pressure has fallen below the low oil pressure warning setpoint under Sensor > Oil Pressure.
Low Fuel Level	Warning	The fuel level has fallen below the low fuel level warning setpoint under Sensors > Fuel Level.
False Restart	Warning	After going into the RUN mode the controller has determined the engine has not started after all and will attempt to do another crank attempt. The fault restart feature under Engine Logic > Timers has to be enabled.
Breaker Tripped	Warning	The "Breaker Trip" switched output has been activated. This output is used to control the generator breaker.
Over Current	Warning	The generator AC current has risen above the Over Current warning setpoint under AC Monitor > O.C. Protection > Basic Alarm.
Fuel In Basin	Warning	The "fuel in basin" switched input has been triggered. This indicates there has been a leak in the fuel tank.
Low Battery	Warning	The main starter battery (the battery the controller is powered from) voltage has fallen below the low battery warning setpoint under Sensors > Battery.
High Battery	Warning	The main starter battery (the battery the controller is powered from) voltage has risen above the high battery warning setpoint under Sensors > Battery.
Low Engine Temp	Warning	The engine temperature has fallen below the low engine temperature warning setpoint set under Sensors > Engine Temp. > Setpoints.
Battle Running	Warning	The "Battle Mode" switched input has been triggered. The controller will not shutdown on any failures. All failures will be ignored.
Under Frequency	Warning	The generator AC frequency has fallen below the Under Frequency warning setpoint set under AC Monitor > Genset Freq. > Setpoints.
Over Frequency	Warning	The generator AC frequency has risen above the Over Frequency warning setpoint set under AC Monitor > Genset Freq. > Setpoints.
Load Imbalance	Warning	The generator load is imbalanced between the A, B, and C phases. This has to be enabled under AC Monitor > O.C. Protection > Imbalance Mode.
Over Voltage	Warning	The generator AC voltage has risen above the over voltage warning setpoint set under AC Monitor > Genset Voltage. Possible issue with the voltage regulator or governing on the engine.

High Fuel Temp	Warning	Doosan G2 electronic engine high fuel warning. This warning comes from the engine ECM over CAN J1939.
Hi Exhaust Temp	Warning	Doosan G2 electronic engine high turbine exhaust temperature. This warning comes from the engine ECM over CAN J1939.
Transducer Low	Warning	The transducer (aka Auxiliary Sensor 5) reading has fallen below the transducer low warning setpoint set under Application Menu > Transducer menu.
Transducer High	Warning	The transducer (aka Auxiliary Sensor 5) reading has risen above the transducer high warning setpoint set under Application Menu > Transducer menu.
Failed To Stop	Failure	The controller shut down the engine -- by turning off the Fuel output and (if enabled) by turning on the Energize-To-Stop output -- but the engine speed did not go to zero after the energize to stop time (under Timers > Engine Logic).
Breaker Failed	Failure	The "Breaker Trip" switched output failed to turn off the breaker. This is triggered if the AC Current is still above 10% of the rated current setpoint. The "breaker trip" failure has to be enabled under AC Monitor > O.C. Protection > Brk Trip Fail.
Load Imbalance	Failure	The generator load is imbalanced between the A, B, and C phases. This has to be enabled under AC Monitor > O.C. Protection > Imbalance Mode with the mode set to "Shutdown Trip".
Over Current	Failure	The generator AC current has risen above the over current failure setpoint set under AC Monitor > O.C. Protection > Basic Alarm.
ECM Shutdown	Failure	Electronic engines only. CAN J1939 DM1 stop lamp is active; the ECM has shutdown the engine.
High Engine Temp	Failure	Engine temperature has risen above the high engine temperature failure setpoint set under Sensors > Engine Temp.
Low Oil Pressure	Failure	Engine oil pressure has fallen below the low oil pressure failure setpoint set under Sensors > Oil Pressure.
Under Speed	Failure	Engine speed has fallen below the under speed failure setpoint set under Sensors > Engine Speed.
Over Speed	Failure	Engine speed has risen above the over speed failure setpoint set under Sensors > Engine Speed.
Low Fuel Level	Failure	The fuel level has fallen below the low fuel level failure setpoint under Sensors > Fuel Level.
Low Battery	Failure	The main starter battery (the battery the controller is powered from) voltage has fallen below the low battery failure setpoint set under Sensors > Battery.
Low Coolant Lvl	Failure	The "Low Coolant Level" switched input is active indicating low coolant level failure.
Over Crank	Failure	The controller exhausted the crank attempts (specified in Timers > Engine Logic > Crank Attempts) and could not start the engine.
Over Voltage	Failure	The generator AC voltage has risen above the over voltage failure setpoint set under AC Monitor > Genset Voltage > Setpoints.
Under Voltage	Failure	The generator AC voltage has fallen below the under voltage failure setpoint set under AC Monitor > Genset Voltage > Setpoints.
Regen Needed	Failure	For electronic engines with a diesel particulate filter (DPF) only. The user must perform a regeneration before running the engine further. Continuing to ignore this message could result in the DPF being damaged and requiring replacement.
Low Air Pressure	Failure	The "Air Press. Fail" switched input is active. Indicates a low air pressure failure condition.
Low Hydraulic	Failure	The "Hyd Pres. Fail" switched input is active. Indicates a low hydraulic pressure failure condition.
High Battery	Failure	The main starter battery (the battery the controller is powered from) voltage has risen above the high battery failure setpoint set under Sensors > Battery.
Loss Of ECM Comm	Failure	For electronic engines only. The "Loss of ECM" under J1939 must be enabled. The controller has not detected engine speed, oil pressure, or engine temperature on it's CAN J1939 port.
Under Frequency	Failure	The generator AC frequency has fallen below the under frequency failure setpoint set under AC Monitor > Genset Freq. > Setpoints.

Over Frequency	Failure	The generator AC frequency has risen above the over frequency failure setpoint set under AC Monitor > Genset Freq. > Setpoints.
DPF SRVC REQ'D!	Failure	For electronic engines with a diesel particulate filter only. Service the DFP ASAP. Damage to the DPF is possible if the engine is run.
SERVICE DPF!!!	Failure	For electronic engines with a diesel particulate filter only. Service the DFP ASAP. Damage to the DPF is likely if the engine is run.
Calibration Fail	Failure	Doosan G2 electronic engine only. Contact Doosan for more information.
High Fuel Temp	Failure	Doosan G2 electronic engine high fuel failure. This failure comes from the engine ECM over CAN J1939.
Hi Exhaust Temp	Failure	Doosan G2 electronic engine high turbine exhaust temperature failure. This failure comes from the engine ECM over CAN J1939.
Engine Stall	Failure	The controller is in the RUN mode and the engine speed has fallen below the crank disconnect speed. The engine stall must be enabled under Timers > Engine Logic.
Transducer Low	Failure	The transducer (aka Auxiliary Sensor 5) reading has fallen below the transducer low failure setpoint set under Application Menu > Transducer menu.
Transducer High	Failure	The transducer (aka Auxiliary Sensor 5) reading has risen above the transducer high failure setpoint set under Application Menu > Transducer menu.

## 5 Settings

The following section relates to settings that can be changed to alter the way the controller performs its functions. Read and review these sections carefully to ensure your settings are set correctly for your engine.

### 5.1 Operator Setup

The following settings are used to change the way the user interacts with the controller. They are not password protected and can be changed by anyone from the front panel.

Name	Range	Default Setting	Description
Lamp Test	-----	-----	Performs a lamp test on the LEDs when selected.
Display > LCD Reverse	-----	-----	Reverses the white and black pixels when selected.
Display > LCD Contrast	5 ~ 95%	50%	Changes the contrast of the LCD.
Display > Page Scroll	1 ~ 10 seconds	5s	Amount of time between each auto scroll of the parameter pages.
Display > Message Pop-Up	1 ~ 10 seconds	2s	Amount of time each message is displayed on the screen before displaying next message in the buffer.
Display > DPF/DEF Display Time	0 ~ 10 seconds	2s	See DPF/DEF aftertreatment in the J1939 Reference Manual for more information.
Display > LCD Backlight Timeout	10 ~ 600 seconds	600s	Amount of time the LCD Backlight stays on after button activity stops.
Display > Default Application Menu	Tank Level / Float Application Wind Machine Application	Tank Level / Float Application	(configurable using RapidCore software only) Sets the front panel application menu. The application menu is the first menu listed in the menu system and is where end users go to configure the controller.
Display > Default Display Page	Display Page 1 Display Page 2 Transducer Tank Page	Display Page 1	(configurable using RapidCore software only) Set the page in run mode that will be displayed after the no button presses timeout is activated.
Display > Display Page 1 Parameters > Display for Line 1 Display for Line 2 Display for Line 3 Display for Line 4	<ul style="list-style-type: none"> <li>Blank Line</li> <li>Engine Speed</li> <li>Battery</li> <li>AC Frequency</li> <li>Current Run Time</li> <li>Engine Hours</li> <li>Oil Pressure</li> <li>Fuel Level</li> <li>Engine Coolant Temperature</li> <li>Ambient Temperature</li> <li>Transducer Start/Stop Temperature</li> </ul>	<p><u>Page 1</u></p> <p>Engine Speed Battery AC Frequency Current Run Time</p> <p><u>Page 2</u></p> <p>Engine Hours Oil Pressure Fuel Level Engine Coolant Temperature</p>	<p>(configurable using RapidCore software only) Two of the RUN mode scrolling pages can be customized. Up to four parameters (lines) per page can be shown.</p> <p>If "Black Line" is set four two consecutive lines then those two lines are removed and all sequent lines are moved up. If only one page is desired then set all lines to "Blank Line" and that page will not be shown.</p> <p><b>Current Run Time</b> - The amount of time the engine has been running since the last start condition. The following two options are meant to be displayed if "Default Application Menu" is set to "Wind Machine Application": <b>Ambient Temperature</b> - This is the value of the Aux 5 transducer which is expected to be set to temperature. <b>Transducer Start/Stop Temperature</b> - This is the "Start" and "Stop" setting in the Sensors &gt; Auxiliary Sensor 5 menu.</p>
Date / Time > Date Change	1 ~ 31 days 1 ~ 12 months 2000 ~ 2099 years	-----	Sets the date.
Date / Time > Time Change	0 ~ 23 hours 0 ~ 59 minutes 0 ~ 59 seconds	-----	Sets the time.



Name	Range	Default Setting	Description
Date / Time > Daylight Savings	Enable or Disable	Enable	Turns Daylight Savings Time on or off. This applies to North America only. Disable for other locations.
Units > Temperature Unit	Fahrenheit or Celcius	Fahrenheit	Selects the temperature display format.
Units > Pressure Unit	PSI or kPa	PSI	Selects the oil pressure display format.
Run from OFF > RUN from OFF	Enable ~ Disable	Enable	When enabled, allows a user to start the engine using the run button while in the OFF mode. When disabled the controller must be placed in AUTO mode before the run button can start the engine.

## 5.2 Application Menu

The application menu allows end users to easily adjust parameters related to their specific application. It is not password protected.

The application menu contents will depend on the Operator Setup > Display > Default Application Menu setting.

One of two menus can be programmed:

1. Tank Level / Float Application Menu
2. Wind Machine Application Menu

### 5.2.1 Tank Level / Float Application Menu

It consists of the six sub menus. All sub menus, with the exception of the Float Autostart setting under the Function menu and the Transducer menu are a mirror of their corresponding setting in the main menu.

Name	Description
Function	Float autostart enable/disable, dual/single floats, and closed loop control adjustments.
Throttling	Adjust intermediate speed and various dwell times. RPM control increment amount.
Transducer	Similar to Auxiliary Sensors but this can be linked to the tank display during run and pressure quantities can take on negative values (down to -9.9 psi). Allows the setup of a sensor input with simplified Auxiliary Sensor like functionality such as warning/failure setpoints and auto start.
Closed Loop	More detailed settings on the operation of the closed loop control.
Week Scheduler	Set days and times to run the engine.
Long Time Run	Allows user to specify the length of time the engine will run when manually started. Engine is automatically shutdown when the time ends.

#### 5.2.1.1 Function Menu

Name	Range	Description
Float Autostart	Disable, Single Float, Dual Float	Determines the float control system type.
Floats	Disable, Fill Tank, Empty Tank	This is a mirror of the "Float Control" setting in the Other Config > Pump System menu.
Maintain Setup	Disable, Maintain In, Maintain Out	This is a mirror of the "System" setting in the Other Config > Process Control > Closed Loop menu. Enables process control.

#### 5.2.1.2 Throttling Menu

This menu is a mirror of various other menus.

Name	Range	Description
RPM Settings	Sub Menu	-----
RPM Settings > Idle RPM	300 ~ 2000 RPM in 1 RPM increments	This is a mirror of the Idle Speed setting under Sensors > Engine Speed. It determines the speed of the engine in idle mode.
RPM Settings > Interm RPM (Intermediate Speed)	500 to 4000 RPM in 1 RPM increments	This is a mirror of the Interm Speed under Other Config > Pump System.
RPM Settings > Rated RPM	500 ~ 4000 RPM in 1 RPM increments	This is a mirror of the same setting under Sensors > Engine Speed. It determines the final engine speed.
RPM Settings > Goal RPM	500 ~ 4000 RPM in 1 RPM increments	This is a mirror of the "Goal Speed" setting under Other Config > Pump System.
Dwell Times	Sub Menu	-----

Name	Range	Description
Dwell Times > Warm-up	0 ~ 600 s in 5 s increments	This is a mirror of the "Warmup Time" setting under Timers > Engine Logic.
Dwell Times > Interm	1 to 300 s in 1 s increments	This is a mirror of the "Interm Delay" setting under Other Config > Pump System.
Dwell Times > Cooldown	0 ~ 600 s in 5 s increments	This is a mirror of the "Cooldown Time" setting under Timers > Engine Logic.
Ramp Times	Sub Menu	-----
Ramp Times > Dwell 1 (Idle to Intermediate)	1 ~ 300 s in 1 s increments	These are mirrors of the same settings under Other Config > <a href="#">Pump System</a> .
Ramp Times > Dwell 2 (Intermediate to Rated)	1 ~ 300 s in 1 s increments	
Ramp Times > Dwell 3 (Rated to Idle)	1 ~ 300 s in 1 s increments	
Ramp Times > TSC1 RPM/s	Disable, 10 ~ 300 RPM/s in 10 RPM/s increments	This is a mirror of the same setting under Sensors > Engine Speed. Changes in engine speed are limited to this maximum.
Bump Speed	Disable, 0 ~ 500 RPM in 1 RPM increments	This is a mirror of the same setting under Other Config > Pump System. It determines the increment in engine speed when doing a manual speed adjustment.

### 5.2.1.3 Transducer Menu

Settings for the Transducer input. This is an input similar to the Auxiliary Sensors under Sensors. Warnings and failures can be set as well as start on low or start on high start conditions.

The transducer input differs from the auxiliary sensors in two ways:

1. The warnings/failures and start conditions can both be active at the same time instead of choosing one or the other as in the auxiliary sensors.
2. There is an option to show a tank display or ambient temperature. See the [Pumping Applications](#) section for more information.
3. For pressure the custom sender table can have negative values (down to -10 PSI).

In RapidCore the transducer is known as "Auxiliary Sensor 5" and is located under Sensors > Auxiliary Sensor 5.

Name	Range	Description
Signal Source	Sub Menu	----
Signal Source > Source	Disable Port A Port B Port C Port D	The sensor input to use for the Transducer feature or set to Disable to disable this feature.
Signal Source > Display	Enable, Disable	Set to enable to display the value of the transducer and the tank icon when the controller is in RUN mode.
Signal Source > Start On	Disable, Low, High	Set an automatic start when signal goes below or above the Start threshold.
Signal Source > Offset	-50.0 ~ 50.0 in 0.1 increments	This applies an offset to the transducer value. This can be used for calibration.
Sender Type	Custom TF1 115F/R240 TF2 231F/R240 TP1 200P/R240 TP2 100P/R240	The sender table to use. A customer sender table can be defined (using the RapidCore Configuration Software) or one of four predefined sender tables can be selected.  TF1/TR2 are float sensors. 115F/R240 means it has a range of 115 °F at 240 Ohms. TP1/TP2 are pressure sensors. Contact DynaGen for more information.
Start Stop	Sub Menu	----

Name	Range	Description
Start Stop > Bypass Time	0 ~ 90 s in 1 s increments	For warnings/failures this sets the amount of time to ignore the input when RUN mode is first entered. For automatic start (if enabled) this sets the amount of time to ignore the input when AUTO mode is first entered. No warnings, failures or start will be triggered during this time even if normally they would be triggered.
Start Stop > Run Time	1 ~ 6000 min in 1 min increments, Disabled	The length of time to run the engine on a Low or High auto start.
Start Stop > Start	0.1 ~ 510 in 0.1 °F / % / ft increments -9.9 ~ 500 in 0.1 psi increments	The threshold at which to start the engine. The "Start On" setting above determines which direction the threshold must be crossed.
Start Stop > Stop	0.1 ~ 510 in 0.1 °F / % / ft increments -9.9 ~ 500 in 0.1 psi increments	The threshold at which to stop the engine. The "Start On" setting above determines which direction the threshold must be crossed.
Thresholds	Sub Menu	-----
Thresholds > Low Warn	Disable 0.1 ~ 510 in 0.1 °F / % / ft increments -9.9 ~ 500 in 0.1 psi increments	The low warning setpoint. Active in run and cooldown modes.
Thresholds > Low Fail	Disable 0.1 ~ 510 in 0.1 °F / % / ft increments -9.9 ~ 500 in 0.1 psi increments	The low failure setpoint. Active in run and cooldown modes.
Thresholds > High Warn	Disable 0.1 ~ 510 in 0.1 °F / % / ft increments -9.9 ~ 500 in 0.1 psi increments	The high warning setpoint. Active in run and cooldown modes.
Thresholds > High Fail	Disable 0.1 ~ 510 in 0.1 °F / % / ft increments -9.9 ~ 500 in 0.1 psi increments	The high failure setpoint. Active in run and cooldown modes.

When the transducer is enabled when the controller is in the RUN mode a tank graphic will be displayed.

#### 5.2.1.4 Closed Loop Menu

These settings mirror those of the same name in Other Config > Process Control.

Name	Range	Description
Parameters	Sub Menu	-----
Parameters > Delay	1 ~ 30 s in 0.1 s increments	The control loop delay and gain. The control gain. The Delay and Gain settings affect how regressive the control is too changes.
Parameters > Gain	1 ~ 30 in 0.1 increments	
Maintain	Sub Menu	-----
Maintain > Main-In	1 ~ 900 in 0.1 increments	The goal value to maintain when the process control feature is set to Maintain-In or Maintain-Out. Engine speed is adjusted to maintain these values. Only one it used at any given time. See Maintain Setup setting in Application > Function menu.
Maintain > Main-Out	1 ~ 900 in 0.1 increments	
Maintain > Deadband+	1 ~ 30 in 0.1 increments	Values in this range do not cause any change in engine speed.
Maintain > Deadband-	1 ~ 30 in 0.1 increments	

### 5.2.1.5 Week Scheduler

These settings mirror those of the same name in Timers > Schedulers.

Name	Range	Description
Scheduler #1	Sub Menu	-----
Scheduler #1 > Weekday	Monday ~ Sunday	The day of the week to run the engine.
Scheduler #1 > Start Time	0:00 ~ 24:00 in 1 min increments	The start time in 24hour clock notation.
Scheduler #1 > Run Time	10 ~ 1440 min in 1 min increments	The amount of time to run the engine.
...	...	...
Scheduler #16	Sub Menu	... There are a total of 16 seperate schedulers than can be programmed.
Scheduler #16 > Weekday	...	...
Scheduler #16 > Start Time	...	...
Scheduler #16 > Run Time	...	...

### 5.2.1.6 Long Time Run Menu

These settings mirror those of the same name in Timers > Long Time Run

Name	Range	Description
Start Trigger	Disable Manual Start	If set to "Manual Start" enables timed shutdown after the time given in "Run Duration" below. This timer only applies to a manual start.
Run Duration	1 ~ 5000 hours (> 208 days) in 1 hour increments	The amount of time to allow the engine to run before shutting it down.

## 5.2.2 Wind Machine Application Menu

The Wind Machine submenu more or less replicates the Application > Transducer menu. None that the transducer input is known as the Auxiliary sensor 5 input in RapidCore.

Name	Range	Description
Wind Machine > Signal Source > Source	Disabled Port-A Port-B Port-C Port-D	Transducer (Aux Sensor 5) port.
Wind Machine > Signal Source > Display	Disabled Enable	Display the transducer (Aux Sensor 5) value.
Wind Machine > Signal Source > Start On	Disabled Low High	Transducer (Aux Sensor 5) start engine triggered on the Aux 5 value dropping below the setpoint or rising above the setpoint.
Wind Machine > Signal Source > Offset	-50 ~ 50 in 0.1 increments	Calibrates the transducer (Aux Sensor 5) sensor with an offset.
Wind Machine > SenderType	(custom) TF1 115F/R240 TF2 231F/R240 TP1 200P/R240 TP2 100P/R240	The sender table to use. (custom) refers to a custom sender table which can be programmed only with the RapidCore Configuration software. The other four are factory defined tables. Sensors are available for these four predefined tables. Contact DYNAGEN on these sensors.
Wind Machine > Start Stop > Bypass Time	0 ~ 90s in 1s increments	The time to ignore the Transducer (Aux Sensor 5) input after a engine start.

Name	Range	Description
Wind Machine > Start Stop > Run Time	Disabled, 1 ~ 6000 minutes in 1 minute increments	On a Transducer (Aux Sensor 5) start the maximum time to run if a stop condition is not triggered.
Wind Machine > Start Stop > Start	0.1 ~ 510 in 0.1 increments	The value of the Transducer (Aux sensor 5) must be below or above this (Signal Source > Start On dependent) to start the engine.
Wind Machine > Start Stop > Stop	0.1 ~ 510 in 0.1 increments	The value of the Transducer (Aux sensor 5) must be below or above this (Signal Source > Start On dependent) to stop the engine.
Wind Machine > Thresholds > Low Warn	0.1 ~ 510 in 0.1 increments	Transducer (Aux Sensor 5) "Low Warning" displayed if the transducer value falls below this set point.
Wind Machine > Thresholds > Low Fail	0.1 ~ 510 in 0.1 increments	Controller shuts down on Transducer (Aux Sensor 5) "Low Failure" if the transducer value falls below this set point.
Wind Machine > Thresholds > High Warn	0.1 ~ 510 in 0.1 increments	Transducer (Aux Sensor 5) "High Warning" displayed if the transducer value rises above this set point.
Wind Machine > Thresholds > High Fail	0.1 ~ 510 in 0.1 increments	Controller shuts down on Transducer (Aux Sensor 5) "High Failure" if the transducer value rises above this set point.

The Throttling submenu more or less replicates settings in the Sensors > Engine Speed menu, the Other Config > Pump System menu, the Timers > Engine Logic menu, and others.

Name	Range	Description
Throttling > RPM Settings > Idle RPM	300 ~ 2000 RPM in 1 RPM increments	The J1939 TSC1 speed sent to the ECM when the controller is in Idle mode.
Throttling > RPM Settings > Intern RPM	500 ~ 4000 RPM in 1 RPM increments	The J1939 TSC1 speed sent to the ECM when the controller is in intermediate mode (between Idle and rated/goal speed).
Throttling > RPM Settings > Rated RPM	500 ~ 4000 RPM in 1 RPM increments	The rated running RPM of the engine. The RPM that corresponds to 50/60Hz or to the tooth count.
Throttling > RPM Settings > Goal RPM	500 ~ 4000 RPM in 1 RPM increments	The J1939 TSC1 speed sent to the ECM when the controller is in normal running mode.
Throttling > Dwell Times > Warm-up	Disabled, 5 ~ 600s in 5s increments	The time to spend in warm-up. The engine is idled if idle is enabled.
Throttling > Dwell Times > Intern	1 ~ 300s in 1s increments	The time to spend at the intermediate speed.
Throttling > Dwell Times > Cooldown	Disabled, 5 ~ 6000s in 5s increments	The time to spend at cooldown if cooldown is enabled. The engine is idled if cooldown idle is enabled under Timers > Engine Logic.
Throttling > Ramp Times > Dwell 1	1 ~ 300s in 1s increments	The time to spend ramping between idle and intermediate speeds.
Throttling > Ramp Times > Dwell 2	1 ~ 300s in 1s increments	The time to spend ramping between intermediate and goal speeds.
Throttling > Ramp Times > Dwell 3	1 ~ 300s in 1s increments	The time to speed ramping down from the goal speed to the idle speed.
Throttling > Ramp Times > Tsc1 RPM/s	Disabled, 10 ~ 300 RPM/s in 10 RPM/s increments	A global setpoint. This limits the maximum rate of change of the TSC1 speed command. This overrides everything else including the dwell times.
Throttling > Bump Speed	0 ~ 500 RPM in 1 RPM increments	The amount to increase the speed (TSC1) when a user presses the speed increment / speed decrement buttons.

## 5.3 Switched Inputs

The controller has five switched inputs which cause the controller to perform a function when activated.

Default settings:

Switched Input	Default Value
Switched Input A	Emergency Stop

Switched Input B	Start / Stop
Switched Input C	Disable
Switched Input D	Disable
Switched Input E	Disable

Switched I/O > Switched IN X:

Name	Range	Description
Function	[Menu] See below.	The function that the switched input performs when active.
Active Mode	[Menu] See below.	Determines the operating conditions under which the switched input can be active. Multiple selections are allowed.
Trigger	[Menu] See below.	The state of the input determining if it is active or inactive.

Switched I/O > Switched IN X > Function:

Name	Active Mode	Description
Disabled	N/A	Input is disabled and has no function.
Start / Stop	Auto, Running	Starts the engine when active, stops the engine when deactivated. It is recommended to set the Trigger mode to Close +BAT for better noise tolerance.  If Trigger mode is set to "Open" or "Close +BAT/GND" the start/stop input will act like a momentary input. A pulse of 2 to 4 seconds will start controller. Another pulse of 2 to 4 second duration is required to stop the controller. If the input is just turned off, the controller will continue to run.
Emergency Stop	Global	When active, shuts down the engine, displays Emergency Stop, and prevents leaving the OFF mode.  CAUTION !!! This should only be used for emergency stop indication on the controller. The installer must provide an independent means to shut down the engine from the emergency stop button such as cutting off fuel. See the typical wiring diagrams for an example on how to wire up the emergency stop.
Idle Mode	Running	See the <a href="#">Idle</a> section under Engine Logic for more information.
Voltage Select 1	Auto	Used for changing the system AC voltage configuration. See <a href="#">AC Voltage Select</a> for more information.
Voltage Select 2	Auto	
Charger Fault (Battery Charger Fault)	Global	Controller displays 'Charger Fault' warning when active.
Mom. Start (Momentary Start)	Auto	Starts or stops the engine when momentarily active for at least 2 seconds. These inputs allow the user to wire separate inputs for start and stop or to use a push button instead of a toggle switch.  Momentary stop will only stop the controller when the reason for start was "momentary start". It will not stop if the front panel run button was used to start the engine.
Mom. Stop (Momentary Stop)	Running	
Configurable Warning 1	Configurable	Controller displays a warning or failure with configurable text* when active. In the case of the configurable failures a shutdown is also performed.  The RapidCore Configuration Software must be used to change the text.
Configurable Warning 2	Configurable	
Configurable Failure 1	Configurable	
Configurable Failure 2	Configurable	The settings under Timers > Trigger Delays > Config Inputs and Timers > Trigger Delays > Config Fail 3 can be set to control the amount of time the input has to be active to trigger.
Configurable Failure 3	Configurable	
Air Press. Fail (Air Pressure Failure)	Cranking	Controller displays 'Low Air Pressure' and shuts down engine when active.

Name	Active Mode	Description
Hyd Pres. Fail (Low Hydraulic Pressure Failure)	Cranking	Controller displays 'Hydraulic Pressure Failure' and shuts down engine when active.
Oil Pres Warn (Low Oil Pressure Warning)	Running	Controller displays 'Oil Pressure Warning' when active.
Cool. Lvl Fail (Low Coolant Level Failure)	Global	Controller displays 'Low Coolant Lvl' and shuts down engine when active.
High Fuel Warning	Global	Controller displays 'High Fuel Level' warning when active.
Lamp Test	Global	Controller performs lamp test when active. If the controller is in the FAILURE mode the LED will remain red. The only indication that the lamp test is active is the LED indicator will alternate between the green and red colors. The LED goes back to it's original state when the switched input is no longer active.
Fuel In Basin	Global	Controller displays 'Fuel In Basin' warning when active.
Battle Mode	After Cranking	Controller ignores all warnings and failures when active. Displays 'Battle Running' when active. If a failure occurs during Battle Mode it is 'latched' and the engine will shutdown on failure when the controller leaves Battle Mode.
Start Inhibit	Global	Controller ignores all start commands and the engine cannot start when active. Once Start Inhibit becomes inactive, starting is enabled again. If the engine is running, activating this input will shut down the engine and place the controller in AUTO mode.
RPM Switch (Primary RPM / 60Hz - Secondary RPM / 50Hz Select)	Auto	Used for changing between Primary and Secondary RPM for an engine or 50Hz / 60Hz for a generator. See <a href="#">RPM / Frequency Select</a> for more information.
ECM Preheat (ECM Preheat Signal)	Cranking (during the Preheat countdown only)	Controls preheating using a switched input. See Switched Input in the <a href="#">Preheat Mode</a> section.
Remote Reset	Global	Allows the controller to be reset from a failure mode. - Momentary action for 3 - 5s in FAILURE mode will place the controller in OFF mode. - Momentary action for 3 - 5s in OFF mode will place the controller in AUTO mode. - Momentary action for 3 - 5s in RUN mode will place the controller in AUTO mode. Cool-down is skipped.

#### TE350 / TE410 Specific Functions

Name	Description
Key Switch	Starts the engine. Equivalent to a manual start. Displays "Keyswitch Start" as the start reason.
Speed Increase	Similar to pressing the front panel Up (speed increment) or Down (decrement buttons). Front panel button has priority. Refer to <a href="#">Manual Speed Control</a> in the Pumping Applications chapter for more information.
Speed Decrease	
Float Input 1	The connection for float sensor 1 and 2 which are used as an auto start means. Refer to the <a href="#">float autostart</a> section in the Pumping Applications chapter and the <a href="#">Pump System</a> section for more information.
Float Input 2	



**NOTE:** More than one Active Mode can be selected.

The active modes is only configurable if the Function menu is set to one of the configurable switched input functions. It is fixed for all other functions.

Switched I/O > Switched IN X > Trigger:

Name	Description
Close +BAT	Input is active when +Battery is present at the terminal.



Name	Description
Close GND	Input is active when Ground is present at the terminal
Close +BAT/GND	Input is active when either +Battery or Ground is present at the terminal.
Open	Input is active when neither +Battery or Ground is present at the terminal.



**NOTE:** When running wires over long distances (over 20ft / 6.1m), it is recommended to use +BATTERY as the trigger method.

### 5.3.1 Configurable Inputs

These inputs are used to create custom warnings and failures. Using the RapidCore Configuration Software you can change the text displayed when the warning or failure occurs. If you select one of these inputs without changing the text it will default to 'Config Warn X' and 'Config Fail X.'

There are also timers associated with the configurable inputs which can be found in the menu under *Timers > Trigger Delays > Config Inputs and Config Fail* 3. These timers change the amount of time the input has to be active before the controller registers the warning or failure.



**NOTE:** If the switched input becomes inactive before the trigger delay time expires, the warning or failure will not occur.

**Example:** The user wants a pump to turn on 30 seconds after a high water level switch is tripped and remain on until the level switch turns off.

The level switch is connected to Switched Input C and closes to ground when the water level is too high. The words 'Water Pumping' are also required to be displayed on the controllers LCD screen. The pump is connected to a slave relay which is controlled by Switched Output D on the controller.

#### Relevant Settings

Setting	Value
Switched Input C -> Function	Configurable Warning 1
Switched Input C -> Active Mode	Global
Switched Input C -> Trigger	Close GND
Configurable Warning 1 Custom Text	Water Pumping
Switched Output D -> Warnings	Configurable Warning 1

### 5.4 Switched Outputs

The controller has switched outputs that are turned on under certain conditions to perform a function. The outputs turn on to +Battery voltage to drive the load when active. The following items are the available functions for switched outputs.



**WARNING:** Switched outputs have a floating voltage of approximately 8V when off. If using the outputs for digital logic, it will be necessary to put a pull-down resistor (1 kOhm) from the output to ground to ensure a low logic level when output is off.

Default settings:

Switched Output	Default Setting
Switched Output A	Fuel Output
Switched Output B	Disable
Switched Output C	Crank Output
Switched Output D	Disable
Switched Output E	Disable
Switched Output F	Disable

#### Event Functions

Name	Active Mode	Description
Fuel	Cranking, Running	Active during cranking and running to supply fuel to engine.
Crank	Cranking	Active during cranking to start the engine.

Name	Active Mode	Description
Pull Coil	Cranking	See <a href="#">Pull and Hold Coil</a> section for more information.
LCD Backlight	Global	Active when LCD Backlight is active.
Voltage Regulator	Running	Active when engine is starting/running and is not in Idle Mode.
ETS (Energize to Stop)	ETS Timer	Active during Energize to Stop timer. See ETS On Duration under Timers > <a href="#">Engine Logic</a> for more details.
Off Mode (Not In Auto)	Off	Active when the controller is in the OFF mode.
Idle Mode	Idle Mode	Active when the controller is in IDLE mode. For example when the idle switched input is active or during warmup and cooldown if warmup idle and cooldown idle settings under Timers > Engine Logic are enabled.
Battle Mode	Battle Mode	Active when Battle Mode switched input is active.
System OK (System Ready)	Auto, Run	Active when the controller is in the AUTO and RUN mode and no warnings or failures are present.
Delay to Start	Delay to Start Timer	Active when the Delay to Start timer is active.
Glowplug	Preheat, Midheat, Postheat	Active during the Preheat, Midheat and Postheat timers.
Warmup	Warmup Timer	Active in RUN mode after Warmup timer has expired. Is not active in the cooling down state or other states. Typically used to apply load to engine only after it has warmed up and to remove the load on cooldown.
Cooldown	Cooldown Timer	Active when Cooldown timer is active.
Engine Running	Running	Active after crank success.
Exercising	Exercise Timer	Active during the engine exercising cycle.
Batt. Recharge (Battery Recharge)	Battery Recharge Timer	Active during the battery recharge cycle.
Maintenance (Maintenance Required)	Global	Active when Maintenance timer has expired. If the timer has expired when the controller is in the RUN mode the output does not turn on until the controller enters the OFF or AUTO mode. See the <a href="#">Maintenance</a> section.
LowBat InCrank (Low Battery During Cranking)	Cranking	Active when Low Battery During Cranking warning is displayed.
Aux Sensor 1	Auxiliary Settings Dependent	Active dependent upon settings in the <a href="#">Auxiliary</a> sensor section.
Aux Sensor 2		
Aux Sensor 3		
Aux Sensor 4		
Force Regen	User Controlled	When user triggers a Force Regeneration, output is active for 20 seconds then switches off.
Regen Inhibit	User Controlled	When user triggers a Regeneration Inhibit, output is active for 20 seconds then switches off.
Common Failure	Any Failure	Active when any failure occurs.
RPM Increment	Running	Output is used to trigger inputs on an ECM to control speed. See <a href="#">Front Panel Speed Control</a> section for more information.
RPM Decrement	Running	Output is used to trigger inputs on an ECM to control speed. See <a href="#">Front Panel Speed Control</a> section for more information.
DEF Fluid Pump	Running	Active when DEF Fluid Level falls below the DEF Low Level and stays active until the level rises above the DEF High Level. See <a href="#">CAN Bus (J1939)</a> section for more information.
Genset Disable	Global	Disables the generator during a stationary Regen on Kubota engines (see Aftertreatment in the J1939 User Manual ) or also during an engine IDLE condition from the IDLE switched input. Automatic idle is ignored. If the generator voltage is not below the under voltage setpoint in 10s, the controller will shut down the engine on "Generator Disable Failure."
Dummy Load	Running	Output is controlled by the <a href="#">dummy load</a> feature.

Name	Active Mode	Description
Breaker Trip	Running	Output is controlled by the <a href="#">Over Current Failure</a> , <a href="#">IDMT</a> , and <a href="#">Load Imbalance</a> features. The breaker Trip only reacts to over current faults; It does not activate for other failures.
Auto Idle	Warm-up, Cooldown	Active at the start of delay to start until the end of warm-up if warmup idle is enabled. Also active during cooldown if cooldown idle is enabled. See Warm-up Idle and Cooldown Idle in <a href="#">Engine Logic</a> . This output does not react to the Idle switched input.

**Warning Functions**

Functions			
Low Engine Temperature	High Engine Temperature	Low Oil Pressure	Under Speed
Over Speed	Low Fuel Level	High Fuel Level	Low Battery Voltage
High Battery Voltage	Under Frequency	Over Frequency	AC Under Voltage
AC Over Voltage	Over Current	Fuel In Basin	Battery Charger Fault
Configurable Warning 1	Configurable Warning 2	Auxiliary Sensor 1	Auxiliary Sensor 2
Auxiliary Sensor 3	Auxiliary Sensor 4		
Name			
Name	Active Mode	Description	
Load Imbalance	Running	AC current phases do not match. ( <a href="#">More Information</a> )	
DTC Received. (DTC/MIL)	Running	Active when controller receives a DM1 from the ECM.	

**Failure Functions**

Functions			
Overcrank	Engine Failed to Stop	DM1 Stop Lamp	High Engine Temperature
Low Oil Pressure	Low Fuel Level	Under Speed	Over Speed
Low Battery Voltage	High Battery Voltage	Low Coolant Level	Low Air Pressure
Low Hydraulic Pressure	Under Frequency	Over Frequency	AC Under Voltage
AC Over Voltage	Over Current (TG410 only)	ECM Communication Failure	Configurable Failure 1
Configurable Failure 2	Config Fail 3	Auxiliary Sensor 1	Auxiliary Sensor 2
Auxiliary Sensor 3	Auxiliary Sensor 4		---
Name			
Name	Active Mode	Description	
Load Imbalance	Running	AC current phases do not match. ( <a href="#">More Information</a> )	
Exception Fault*	All	When the controller encounters an unhandled exception or lockup (watchdog triggered) it will reset and enter the failure mode as an exception fault.  *The name of this fault is configurable form the Configuration Software.	

### 5.4.1 Group Outputs

Group functions have been designed to allow multiple output functions to be bundled together and assigned to a single switched output pin. The definition of a group output follows:

*When any of the functions in a group is active (OR logic), the assigned switched output will be active.*

#### Group Functions

Name	Active Mode	Description
Group #1	Group Dependent	Must be set from RapidCore Configuration software.
Group #2	Group Dependent	Must be set from RapidCore Configuration software.
Group #3	Group Dependent	Must be set from RapidCore Configuration software.
Group #4	Group Dependent	Must be set from RapidCore Configuration software.

**Example:** Low AC Frequency, High AC Frequency are bundled in 'Group #1' and assigned to Switched Output D. This output is connected to an external indicator lamp labeled 'AC Frequency Warnings', allowing one output to indicate there is a warning with the AC frequency. The following table shows the output state based on the warnings status.

Low AC Frequency Warning	High AC Frequency Warning	Switched Output State
Inactive	Inactive	OFF
Inactive	Active	ON
Active	Inactive	ON
Active	Active	ON


### 5.4.2 Pull and Hold Coil

On some engine systems the fuel pump has two coils. This is because the initial power on of the fuel solenoid requires substantial current (Pull Coil), but only needs a small amount of current to hold it in place (Hold Coil).

1. Hold Coil (Fuel) is energized.
2. Pull Coil is energized for the first 1.6 to 1.8 seconds of preheat. If preheat is disabled the pull coil is energized at the beginning of cranking; the crank output turned off for that time period.
3. This is repeated for each crank attempt.

Configuring a switched output to Pull Coil automatically configures the engine logic necessary for a Pull Coil system.

Note: The pull coil feature does not operate when the fuel output is activated by the Auto Power ECM feature or when requesting stored DTCs (DM2 codes). See the J1939 section for more information on these features.



## 5.5 Sensors

The controller has four sensor inputs which can be connected to a variety of different sensors/switches depending on the input. See the [Terminal Descriptions](#) section for more information regarding the sensor types supported.

To configure the behavior of these sensor inputs the user assigns the sensor input to one of the following 7 sensor functions:

- Engine Temperature,
- Oil Pressure,
- Fuel Level
- Auxiliary Sensor 1
- Auxiliary Sensor 2
- Auxiliary Sensor 3
- Auxiliary Sensor 4

Note that there are more sensor functions than sensor inputs as the Auxiliary Sensors can be assigned the same sensor input as the other sensor functions.

- The Engine Temperature, Oil Pressure, and Fuel Level functions are mostly fixed in functionality but the [Auxiliary](#) sensors can be configured to perform specific shutdowns or special functions (Example: Starting engine on low temperature).
- The Engine Temperature, Oil Pressure, and Fuel Level functions can be set to work with a switch or a sender/sensor but the Auxiliary sensors can only work with a sender.

Note: The engine speed and battery level are built in and do not need to be assigned to a pin.

### 5.5.1 Engine Temperature

Use the following settings' configurations to allow the controller to read and interpret data from the engine temperature sensor or switch.

(Sensors > Engine Temp. menu)

Name	Range	Default Settings	Description
Signal Source	Port A Port B Port C Port D J1939 Bus*	Port A	The sensor input pin where the engine temperature switch or sender is attached.  *Engine temperature is obtained from the engine controller (ECM) using the CANbus communication port and J1939 protocol.
Sensor Type	DAT DAH* VDO 250F*  (custom sender)**  Close = Warning+ Open = Warning+ Close = Failure+ Open = Failure+	DAT DAH	Select the sender that is connected to the Signal Source above. If using a switch select the action that should occur when the switch is active.  *These are preprogrammed into the controller and cannot be changed. - DAT DAH supports all Datcon type DAH (high range) temperature sensors such as 02022-00. - VDO 250F supports the VDO 323-420 or equivalent temperature sensor. DAT DAH and VDO 250F can only be used if the Signal Source is set to Port A, C, or D. To use on other ports store as a custom sender table using the RapidCore Configuration software.  **A custom table can be created using the RapidCore Configuration Software. The text (custom sender) will be replaced with the custom text you choose when creating the sender.  +The switch must close to ground.
Trim Offset	-50.0 ~ 50.0°F (-10 ~ 10°C)	0.0 F	Calibrate a sensor by using the offset to correct errors. Only applies if Sensor Type has been set to a sender.
Setpoints > Bypass Time	0 ~ 90 seconds	30 s	Amount of time to bypass warnings and failures after engine has started.
Setpoints > Low Warn (Low Warning)	Disabled, 32 ~ 200°F (0 ~ 93.3°C)	Disabled	Reading at which a "Low Engine Temp" warning occurs. Displays 'Low Engine Temp' on the screen. Only applies if Sensor Type has been set to a sender. Monitored globally including OFF and AUTO.
Setpoints > High Warn (High Warning)	Disabled, 50 ~ 300°F (10 ~ 148.9°C)	200 F	Reading at which a "High Engine Temp" warning occurs. Only applies if Sensor Type has been set to a sender. Only monitored in the RUN mode.

Name	Range	Default Settings	Description
Setpoints > High Fail (High Failure)	Disabled, 50 ~ 300°F (10 ~ 148.9°C)	220 F	Reading at which a "High Engine Temp" failure occurs. Only applies if Sensor Type has been set to a sender. Only monitored in the RUN mode.

Note: All temperature settings are entered in terms of Fahrenheit.

## 5.5.2 Oil Pressure

Use the following settings' configurations to allow the controller to read and interpret data from the oil pressure sensor or switch.

Name	Range	Default	Description
Signal Source	Port A Port B Port C Port D J1939 Bus*	Port B	The sensor input pin where the oil pressure switch or sender is attached.  *Oil pressure is obtained from the engine controller (ECM) using the CANbus communication port and J1939 protocol.
Sensor Type	DAT 100P/R240* VDO 150P/R180*  (custom sender)**  Close = Warning+ Open = Warning+ Close = Failure+ Open = Failure+	DAT 100P/R240 (Stear 279B-F)	Select the sender that is connected to the Signal Source above. If using a switch select the action that should occur when the switch is active.  *These are preprogrammed into the controller and cannot be changed. - DAT 100P/R240 supports the Stewart - Warner 279B-F and Datcon 2505-00 sender tables. - VDO 150P/R180 supports the VDO 360-004 oil pressure sender. DAT 100P/R240 and VDO 150P/R180 can not be used on port A. To use on port A store as a custom sender table using the RapidCore Configuration software.  **A custom table created using the RapidCore Configuration Software. The text (custom sender) will be replaced with the custom text you choose when creating the sender.  +The switch must close to ground.
Trim Offset	-50.0 ~ 50.0 PSI (-344.7 ~ 344.7kPa)	0 PSI	Calibrate a sensor by using the offset to correct errors. Only applies if Sensor Type has been set to a sender.
Setpoints -> Bypass Time	0 ~ 90 seconds	30 s	Amount of time to bypass warnings and failures after engine has started.
Setpoints -> Low Warning	Disabled, 0.1 ~ 99.0 psi (0.7 ~ 682.6kPa)	20.0 PSI	Reading at which a "Low Oil Pressure" warning occurs. Only applies if Sensor Type has been set to a sender.
Setpoints -> Low Failure	Disabled, 0.1 ~ 99.0 psi (0.7 ~ 682.6kPa)	15.0 PSI	Reading at which a "Low Oil Pressure" failure occurs. Only applies if Sensor Type has been set to a sender.

Note: All pressure settings are entered in terms of psi.

## 5.5.3 Fuel Level

Use the following settings' configurations to allow the controller to read and interpret data from the fuel level sensor.

Name	Range	Default	Description
Signal Source	Disable Port A Port B Port C Port D	Disable	The sensor input pin where the fuel level switch or sender is attached.
Sensor Type	DAT R/33-240* VDO R/0-180*  (custom sender)**	Close = Failure	Select the sender that is connected to the Signal Source above. If using a switch select the action that should occur when the switch is active.  *These are preprogrammed into the controller and cannot be changed. - DAT R33-240 supports a Dacon fuel level sensor of the range 33 Ohms to 180 Ohms

Name	Range	Default	Description
	Close = Warning <sup>+</sup> Open = Warning <sup>+</sup> Close = Failure <sup>+</sup> Open = Failure <sup>+</sup>		- VDO R/0-180 supports a VDO fuel level sensor of the range 0 Ohms to 180 Ohms DAT R33-240 and VDO R/0-180 can not be used on port A. To use on port A store as a custom sender table using the RapidCore Configuration software.  **A custom table created using the RapidCore Configuration Software. The text (custom sender) will be replaced with the custom text you choose when creating the sender.  <sup>+</sup> The switch must close to ground.
Trim Offset	-50.0 ~ 50.0%	0.0 %	Calibrate a sensor by using the offset to correct errors. Only applies if Sensor Type has been set to a sender.
Setpoints -> Bypass Time	0 ~ 90 seconds	30 s	Amount of time to bypass warnings and failures after engine has started.
Setpoints > Low Warning	Disabled, 1 ~ 90%	25 %	Reading at which a "Low Fuel Level" warning occurs. Only applies if Sensor Type has been set to a sender. Only monitored in the RUN mode.
Setpoints > Low Failure	Disabled, 1 ~ 90%	5 %	Reading at which a "Low Fuel Level" failure occurs. Only applies if Sensor Type has been set to a sender. Only monitored in the RUN mode.
Setpoints > High Warning	Disabled, 1 ~ 125%	Disabled	Reading at which a "High Fuel Level" warning occurs. Displays 'High Fuel Level' on the screen. Only applies if Sensor Type has been set to a sender. Monitored globally including OFF and AUTO.

### 5.5.4 Engine Speed

Use the following settings' configurations to allow the controller to read and interpret speed sensing data.

Name	Range	Default	Description
Signal Source	J1939 Bus Mag Pickup Genset Voltage	Genset Voltage	The source for the engine speed signal.  <b>J1939</b> -- Engine speed is obtained over the engine CAN communication bus . <b>Genset Voltage</b> -- The AC Voltage connector phase A is used for engine speed. <b>Mag Pickup</b> -- A magnetic pickup, alternator output, or the distributor signal can be used to sense speed. Must use J6 pins 7 and 8. If using a distributor a filter is often required. Contact DYNAGEN for more information on using a distributor signal.
Speed Settings > Rated RPM	500 ~ 4000 rpm in 1 rpm increments	1800 rpm	Speed at which the engine runs under normal operating conditions. Warning and failure setpoints are calculated from this setting.
Speed Settings > Idle RPM	300 ~ 2000 rpm in 1 rpm increments	900 rpm	Speed at which the engine runs when it is idling.
Speed Settings > Tooth Count	1 ~ 600	110	(only applies when Signal Source is set to Mag Pickup) Number of teeth on the flywheel.  If the number of teeth is unknown the following formula can be used. A multimeter must be used to measure the AC frequency (Frequency-In-Hz below) from the magnetic pickup. The speed (Speed-In-Rpm below) must be known.  $\text{Tooth-Count} = (\text{Frequency-In-Hz} * 60) / \text{Speed-In-Rpm}$
Setpoints > Low Warn (Under Speed Warning)	20 ~ 99%	90 %	Reading at which a warning occurs.
Setpoints > Low Fail (Under Speed Failure)	20 ~ 99%	85 %	Reading at which a failure occurs.
Setpoints > High Warn (Over Speed Warning)	101 ~ 150%	110 %	Reading at which a warning occurs.



Name	Range	Default	Description
Setpoints > High Fail (Over Speed Failure)	101 ~ 150%	115 %	A over speed failure is triggered if the speed is above this threshold for 4 seconds.
RPM Control > Min Speed	500 ~ 4000 rpm in 1 rpm increments	600 rpm	Front Panel Speed Control SettingsSee <a href="#">Front Panel Speed Control</a> section for more information on these settings.
RPM Control > Max Speed	500 ~ 4000 rpm in 1 rpm increments	2000 rpm	
RPM Control > Speed Bias	0 to 600 rpm in 1 rpm increments	30 rpm	
RPM Control > Tsc1 RPM/s	Disabled, 10 to 300 rpm in 10 RPM increments	200 rpm	
RPM Display	Blank AC Hertz Aux Sensor 1 Aux Sensor 2	AC Hertz	
RPM Switch > Secondary (Secondary RPM / 50Hz)	500 ~ 4000 rpm in 1 rpm increments	1500 rpm	The Rated RPM when the Secondary RPM / 50Hz is selected. See <a href="#">RPM / Frequency Select</a> section for more information.
RPM Switch > Primary (Primary RPM / 60Hz)	500 ~ 4000 rpm, 1 rpm increments	1800 rpm	The Rated RPM when the Primary RPM / 60Hz is selected. See <a href="#">RPM / Frequency Select</a> section for more information.

**NOTE:** When using J1939 or Genset Voltage as a signal source, connections to the speed sensing terminals are not required.

**IMPORTANT:** When using Genset Voltage as a signal source the voltage source must be connected to terminal A (J7-1). AC frequency is sensed on terminal A only.



**NOTE:** Speed is monitored at the start of cranking. If there is speed detected above the crank disconnect setting then cranking and idle is skipped.

The speed is not monitored during delay-to-start or preheat as this provides some degree of protection against spurious signals due to noise. The fuel input is turned on at the start of preheat and often powers external equipment that can cause noise.

### 5.5.4.1 Front Panel Speed Control

The operator is able to adjust the speed of the engine by using the controller's front panel. This section describes the two methods available for implementing speed control, the settings and parameters to be used, as well as the necessary instructions allowing the operator to control the speed.

#### Speed Control Methods

Setting	Description
Front Panel Speed Control using J1939 TSC1	The controller can instruct the ECM of an electronic engine to adjust its speed by broadcasting the TSC1 command.  Refer to the J1939 Manual for more information.
Front Panel Speed Control using Switched Outputs	The controller can instruct the ECM of an electronic engine to adjust its speed by using switched outputs on the controller set to RPM Increment and RPM Decrement to interface with digital inputs on the ECM. When the speed is changed, the corresponding switched output will be on for 1 second each time increment or decrement is pressed.  See the rest of this section for more information.
Aux 4 Speed Control	The Auxiliary sensor 4 is used to determine the setpoint speed. The speed is adjusted with the TSC1 J1939 command.  Refer to the J1939 Manual for more information.



**WARNING:** Switched outputs have a floating voltage of approximately 8V when off. If using the outputs for digital logic, it will be necessary to put a pull-down resistor (1kOhm, 1 Watt) from the output to ground to ensure a low logic level when output is off.


#### Front panel speed control using the Switched Outputs

##### Settings


Name	Parent Menu	Range	Default	Description
Speed Control Enable	RapidCore only. Engine Speed menu.	Enable or Disable	Disable	(Programmable from RapidCore Configuration Software only) Enables or disables front panel speed control.
RPM Display	Sensors > Engine Speed	Blank AC Hertz Aux Sensor 1 Aux Sensor 2	AC Hertz	Parameter to display when adjusting speed from front panel. This is used to provide operator feedback in the case that the engine RPM affects another parameter such as AC Frequency or an Auxiliary Sensor (Example: Flow rate of pump).
Limit Method	RapidCore only. Engine Speed menu.	Speed Bias Min RPM / Max RPM	Speed Bias	(Programmable from RapidCore Configuration Software only) The method in which the minimum and maximum speeds the operator is allowed to adjust is determined.
Speed Bias	Sensors > Engine Speed > RPM Control	0 ~ 600 RPM in 1 RPM increments	30 RPM	The minimum or maximum RPM that the engine speed can be adjusted around the Rated RPM. Example: Rated RPM is 1800 and Speed Bias is 150. The minimum RPM will be 1650 and maximum RPM will be 1950. Only valid when the correct limit method is chosen.
Min Speed		500 ~ 4000 RPM in 1 RPM increments	600 RPM	The minimum RPM that can be set using speed control. Only valid when the correct Limit Method is chosen.
Max Speed		500 ~ 4000 RPM in 1 RPM increments	2000 RPM	The maximum RPM that can be set using speed control. Only valid when the correct Limit Method is chosen.
Tsc1 RPM/s	Sensors > Engine Speed > RPM Control	Disable, 10 ~ 300 RPM/s in 10 RPM/s increments	200 RPM	Ignore this setting. Refer to the J1939 reference manual for information on this setting.

#### Speed Control Instructions

When the controller is running and there are other functions occurring, the controller will scroll through its display parameters as usual. When the speed control page is displayed, it will show the Engine Speed as well as the following instructions: Hold AUTO + Up/Down to Adjust RPM.



Speed Control Parameter Page



Speed Control Adjust Page

Pressing and holding the AUTO button will display the screen to the right. If a 'Display Adjust Parameter' is set, it will also be displayed underneath the Engine Speed. While still holding the AUTO key, press the up or down arrows to adjust the RPM. The Engine Speed display should update as the engine physically changes its speed to accommodate the speed request.



**NOTE:** When using switched outputs for speed control, the Set RPM will display '---' instead of the set speed.

### 5.5.5 Battery


Use the following settings' configurations to allow the controller to read and interpret the battery voltage level.

Name	Range	Default	Description
Battery Recharge	Enable ~ Disable	Disable	Enables or disables the ability to have the engine start on low battery voltage in order to charge it.
Recharge Setup -> Level	6.0 - 30.0V	10.4 V	Voltage level at which the controller starts the engine to recharge the battery.
Recharge Setup -> Pre-Alarm	1 ~ 30 minutes	5 min	Amount of time to display a warning before starting the engine.
Recharge Setup -> Duration	10 ~ 900 minutes	90 min	Amount of time to run the engine.
Setpoints -> Low Warning	Disabled, 6.0 ~ 24.0V	11.3 V	Reading at which a warning occurs.
Setpoints -> Low Failure	Disabled, 6.0 ~ 24.0V	Disabled	Reading at which a failure occurs.
Setpoints -> High Warning	Disabled, 12.0 ~ 32.0V	Disabled	Reading at which a warning occurs.
Setpoints -> High Failure	Disabled, 12.0 ~ 32.0V	Disabled	Reading at which a failure occurs.
LowBat InCrank	6.0 ~ 24.0V	8.0 V	Screen displays a 'Low Voltage During Cranking' warning if voltage dips below this level during cranking.



**NOTE:** When the engine is running, the battery voltage will equal the alternator charging voltage. The actual open-circuit battery voltage may be lower than displayed.

#### Battery Recharge Sequence



### 5.5.6 Auxiliary Sensors

The Auxiliary sensors are used for supporting custom sensors and triggering actions based on the sensor values. There are four auxiliary sensors.

Note: there is a fifth sensor - Transducer Sensor (Auxiliary Sensor 5 in RapidCore) - that is similar to the auxiliary sensors. It is set in the Application Menu > [Transducer Menu](#) (or Sensors > Auxiliary Sensor 5 in RapidCore). The below menus are for the Auxiliary Sensors only.



You must use the RapidCore Configuration Software to program a custom sender table to the controller for the auxiliary sensor(s) that will be used. Otherwise "Undefined" will appear menu in the front panel menu system. Once a sender table is programmed to the controller all the other settings can be adjusted from the front panel of the controller.

(Sensors > Aux Sensor 1/2/3/4 menus)

Name	Range	Default	Description
Signal Source	Disable Port A Port B Port C Port D	Disable	The source where to get the signal for the aux. sensor.  Any port can be used even if it is used by another sensor or aux. sensor. If the port is in use by other sensor this is known as <i>overloading</i> the port.
Custom Sender (Configuration Software only)	-----	Undefined	The sender resistance / value curve must be programmed from the RapidCore Configuration Software even if the port is being overloaded. This tells the controller how to interpret the signal from the port. No front panel configuration is allowed until the sender curve is programmed to the controller.
Display	Enable Disable	-----	Determines if the sensor's value is displayed on the screen when the engine is running.
Active Mode	Disable Global OFF Mode (Not in Auto) Auto Mode Running Cranking After Cranking Cooldown	-----	Determines under which operating conditions the Auxiliary Sensor is monitored. Multiple selections are allowed. Does not apply to "Start on Low" or "Start on High"; for those selections the active mode is always AUTO.  Refer to the examples in the following pages for information on specific mode functions.  Disable - Input cannot be triggered. Global - Input can be triggered at any time. OFF Mode - Input can be triggered while in the OFF mode. Auto Mode - Input can be triggered while in the AUTO mode. Running - Input can be triggered after a start command is received until shut down (cooldown not included). Cranking - Input can be triggered during cranking. After Cranking - Input can be triggered after engine has started until shut down. Cooldown - Input can be triggered while cooldown timer is active.
Func. Select	<a href="#">Fault Monitor</a> <a href="#">Output on Low</a> <a href="#">Output on High</a> <a href="#">Start on Low</a> <a href="#">Start on High</a>	-----	Determines how the controller responds to the readings of the auxiliary sensor.  "x on Low" will turn on the output or start the controller if the sensor input falls below the Start Level. "x on High" will turn on the output or start the controller if the sensor input rises above the Start Level.
Trim Offset	-50.0 ~ 50.0 units. The units depends on the unit type of the programmed sender table -- °F, psi, %, V, A.	-----	Calibrate a sensor by using the offset to correct errors.
Mode Settings > Bypass Time	0 ~ 90, 1 second increments	-----	The amount of time to ignore the sensor input after the desired active mode is first entered. Once triggered the bypass time does not apply again until the device resets (for example transitioning from RUN to the OFF or AUTO state) or on power-up.
Mode Settings > Run Time	Disable	-----	(Only applies if Func. Select is <b>not</b> set to Fault Monitor) The amount of time to turn on the auxiliary switched output or run the

Name	Range	Default	Description
	1 ~ 6000 <sup>1</sup> , 1 minute increments		controller before turning off the output or shutting down the controller.  If the Run Time is disabled then the start/output is held until the Stop Level is reached (if enabled) or until the controller is reset or powered down or, in the case of Start on Low / Start on High, until the user presses the OFF button.  Note that the run time is not exact. Up to 10 seconds may be added to the beginning of the run time counter and up to 4 seconds to the end. The run time begins when a start request is received so crank time, preheat time, etc is included in the Run Time.
Mode Settings > Start Level	Disable Temperature: 32 ~ 999, 1 °F increments Pressure: 1 ~ 6000, 1 psi increments Level: 1 ~ 99, 1 % increments Voltage: 0.1 ~99.9, 0.1 V increments Current: 1 ~ 999, 1 A increments	-----	(Only applies if Func. Select is <b>not</b> set to Fault Monitor) The level at which the auxiliary switched output turns on or the engine starts.  If this is set to Disable, the Aux sensor action defined in Func. Select is disabled. The Auxiliary sensor becomes display only (unless Func. Select is set to Fault Monitor).
Mode Settings > Stop Level			(Only applies if "Func. Select" is <b>not</b> set to Fault Monitor) The level at which the auxiliary switched input turns off or the engine is stopped.  If Stop Level is disabled the start/output condition is maintained until the Run Time expires (if enabled) or until the controller is reset or powered down or in the case of a start until the user presses the OFF button.
Setpoints > Low Warning			(Only applies if "Func. Select" is set to Fault Monitor) Reading at which a warning occurs.
Setpoints > Low Failure			(Only applies if "Func. Select" is set to Fault Monitor) Reading at which a failure occurs.
Setpoints > High Warning			(Only applies if "Func. Select" is set to Fault Monitor.) Reading at which a warning occurs.
Setpoints > High Failure			(Only applies if "Func. Select" is set to Fault Monitor.) Reading at which a failure occurs.
Timers > Trigger Delays Aux Sensors menu:			
Aux 1	1 to 45 s, 1 s increments	5 s	<u>"Func. Select" set to fault monitor:</u> Sets the amount of time to ignore the input for warning and failure detection purposes. No warnings or failures will be generated during this time. Does not apply to other "Func. Select" modes.
Aux 2			
Aux 3			
Aux 4			

<sup>1</sup> 1 ~ 600 minutes for firmware versions below 1.78.

If using *Output on Low* or *Output on High* one of the switched outputs events must be set to one of the following corresponding to the Aux. Sensor being configured per the table below.

(Switched I/O > Switched Out A/B/C/D/EF > Events menus)

Name	Description
Aux Sensor 1	Used by the Aux. Sensor 1 <i>Output On Low</i> or <i>Output on High</i> feature.
Aux Sensor 2	Used by the Aux. Sensor 2 <i>Output On Low</i> or <i>Output on High</i> feature.
Aux Sensor 3	Used by the Aux. Sensor 3 <i>Output On Low</i> or <i>Output on High</i> feature.
Aux Sensor 4	Used by the Aux. Sensor 4 <i>Output On Low</i> or <i>Output on High</i> feature.

The display resolution of the auxiliary sensors that are displayed on the screen are different than the resolution used for the purpose of the comparisons that determine if the start level, stop level, low warning, etc are in effect. The resolutions are given below.

Sensor Unit Type	Comparison Resolution
Temperature	1 °F
Pressure	1 psi
Level	1 %
Voltage	0.1 V
Current	1 A

Example: if the auxiliary sensor 1 (aux 1) is using a temperature sender curve, set to Output on Low, and the Start Level is set to 130 °F then the Output will not turn on until the temperature drops to 129 °F since the resolution for comparisons is 1 °F.

The below tables gives all the possible actions that the auxiliary sensors can perform.

	Behavior	Func. Select	Start Level	Run Time	Stop Level
A - Indefinitely	Start controller when the sensor drops below a certain value. Run indefinitely. <sup>1</sup>	Start on Low	Set to value that the sensor needs to drop below to start.	Disable	Disable
	Turn on an output when the sensor drops below a certain value. Keep on the output indefinitely. <sup>2</sup>	Output on Low	Set to value that the sensor needs to drop below to turn on the output.	Disable	Disable
	Start controller when the sensor rises above a certain value. Run indefinitely. <sup>1</sup>	Start on High	Set to value that the sensor needs to rise above to start.	Disable	Disable
	Turn on an output when the sensor rises above a certain value. Keep the output on indefinitely. <sup>2</sup>	Output on High	Set to value that the sensor needs to rise above to turn on the output.	Disable	Disable
B - Fixed Duration	Start controller when the sensor drops below a certain value. Run for a fixed period of time and then stop controller.	Start on Low	Set to value that the sensor needs to drop below to start.	Set to the desired run duration.	Disable
	Turn on an output when the sensor drops below a certain value. Run for a fixed period of time and then turn off the output.	Output on Low	Set to value that the sensor needs to drop below to turn on the output.	Set to the desired duration to keep the output on.	Disable
	Start controller when the sensor rises above a certain value. Run for a fixed period of time and then stop controller.	Start on High	Set to value that the sensor needs to rise above to start.	Set to the desired run duration.	Disable
	Turn on an output when the sensor rises above a certain value. Run for a fixed period of time and then turn off the output.	Output on High	Set to value that the sensor needs to rise above to turn on the output.	Set to the desired duration to keep the output on.	Disable
C - Start Level / Stop Level	Start controller when the sensor drops below a certain value. Stop controller when the sensor rises above a certain value.	Start on Low	Set to value that the sensor needs to drop below to start.	Disable	Set to the value the sensor needs to rise above to stop the controller.
	Turn on an output when the sensor drops below a certain value. Turn off output when the sensor rises above a certain value.	Output on Low	Set to value that the sensor needs to drop below to turn on the output.	Disable	Set to the value the sensor needs to rise above to turn off the output.
	Start controller when the sensor rises above a certain value. Stop controller when the sensor drops below a certain value.	Start on High	Set to value that the sensor needs to rise above to start.	Disable	Set to the value the sensor needs to drop below to

					stop the controller.
	Turn on an output when the sensor rises above a certain value. Turn off output when the sensor drops below a certain value.	Output on High	Set to value that the sensor needs to rise above to turn on the output.	Disable	Set to the value the sensor needs to drop below to turn off the output.
D - Start Level / Stop Level with timeout	Start controller when the sensor drops below a certain value. Stop controller when the sensor rises above a certain value. Stop the controller after a fixed time if the stop level is not reached.	Start on Low	Set to value that the sensor needs to drop below to start.	Set to the desired maximum run duration (i.e. this is the timeout).	Set to the value the sensor needs to rise above to stop the controller.
	Turn on an output when the sensor drops below a certain value. Turn off output when the sensor rises above a certain value. Turn off the output after a fixed time if the stop level is not reached.	Output on Low	Set to value that the sensor needs to drop below to turn on the output.	Set to the desired maximum duration to keep the output on (i.e. this is the timeout).	Set to the value the sensor needs to rise above to turn off the output.
	Start controller when the sensor rises above a certain value. Stop controller when the sensor drops below a certain value. Stop the controller after a fixed time if the stop level is not reached.	Start on High	Set to value that the sensor needs to rise above to start.	Set to the desired maximum run duration (i.e. this is the timeout).	Set to the value the sensor needs to drop below to stop the controller.
	Turn on an output when the sensor rises above a certain value. Turn off output when the sensor drops below a certain value. Turn off the output after a fixed time if the stop level is not reached.	Output on High	Set to value that the sensor needs to rise above to turn on the output.	Set to the desired maximum duration to keep the output on (i.e. this is the timeout).	Set to the value the sensor needs to drop below to turn off the output.
E - Warnings / Failures	Trigger warnings and/or failures on the sensor.	Fault Monitor	N/A	N/A	N/A
F - Display only	Do not perform any actions on the sensor value. Just display the value to the user.	Fault Monitor (Disable all warnings and failures)	N/A	N/A	N/A



<sup>1</sup> The user must manually stop the controller by pressing the off button.

<sup>2</sup> The controller must be


- powered down or
- a reset initiated by
  - going from the RUN mode to the AUTO or OFF mode, or
  - changing a setting in the menu and exiting the menu system.

#### 5.5.6.1 Fault Monitor Example

In this example, a sensor is monitoring the temperature of an engine block. If the temperature rises above 275°F, a warning message is displayed. If the temperature rises above 350°F, the engine shuts down and a failure message is displayed.

##### Relevant Settings

Setting	Value
Signal Source	Same as Engine Temperature
Display	Disable (If enabled, controller will display Engine Temperature twice)
Sensor Type	Same as Engine Temperature
Sensor Table Name	Engine Temp.
Active Range	Running
Mode Select	Fault Monitor
Setpoints -> Low Warning	Disabled
Setpoints -> Low Failure	Disabled
Setpoints -> High Warning	275°F
Setpoints -> High Failure	350°F



The chart above shows the connection between engine temperature and time. At approximately 13 minutes run time, the temperature rises above the 275°F warning threshold, activating the warning display. The engine will continue to run because it has not reached the 350°F failure threshold. At 20 minutes run time, the temperatures falls below the warning threshold and the warning disappears.


### 5.5.6.2 Start on Low Example

In this example, a sensor is monitoring the voltage of an external battery bank. If the voltage falls below 10.5V, the engine will start and run for 40 minutes to charge the battery.

#### Relevant Settings

Setting	Value
Signal Source	Sensor Port X
Display	Enable
Sensor Type	Custom
Sensor Table Name	Battery Bank
Active Range	N/A (These ranges are fixed for Start on Low / High)
Mode Select	Start on Low
Mode Settings -> Active Time	40 minutes
Mode Settings -> Start Level	10.5V
Mode Settings -> Stop Level <sup>1</sup>	Disabled

<sup>1</sup> Stop Level needs to be disabled when the engine is running because the battery voltage will equal the alternator charging voltage. Having this disabled will force the engine to run for the entire duration of the active time.



The chart above shows the connection between a battery bank and time. At approximately 80 minutes time, the voltage falls below the 10.5V start threshold causing the engine to start. The engine runs for the 40 minutes active time regardless of the voltage reading and then shuts down.

### 5.5.6.3 Output on High Example

In this example, a sensor is monitoring the temperature of an engine. If the temperature rises above 325°F, a fan will turn on to cool the engine. Once the temperature drops to below 200°F the fan will turn off.


#### Relevant Settings (Auxiliary Sensor)

Setting	Value
Signal Source	Same as Engine Temperature
Display	Disable (If enabled, controller will display Engine Temperature twice)
Sensor Type	Same as Engine Temperature
Sender Table Name	Engine Temp.
Active Range	Global
Mode Select	Output on High
Mode Settings -> Active Time <sup>1</sup>	Disabled
Mode Settings -> Start Level	325°F
Mode Settings -> Stop Level	200°F

<sup>1</sup> Active time is disabled because the fan needs to stay on indefinitely or until 200°F is reached.

#### Relevant Settings (Switched Outputs)

Setting	Value
Switched Output X	Auxiliary Sensor X (Choose based on which Auxiliary Sensor is being used)



The chart above shows the connection between engine temperature and time. At approximately 10 minutes run time, the temperature rises above the 325°F start threshold and the fan turns on. The fan continues to run as the temperature declines. When the temperature falls below the 200°F stop threshold, the fan turns off.

## 5.5.7 Custom Sensor Tables

Custom Sensor Tables are created using the RapidCore Configuration Software when using a sensor that is not supported by DYNAGEN. The configurator has the ability to create these custom tables, allowing the controller to properly read the sensor data.



**NOTE:** Custom sender tables can only be created when using the configuration software.

Parameter	Description
Name	The label that will be displayed in the controller (Engine Temp, Oil Pressure, etc.)
Input Type	Choose resistance, voltage or current based on the sensor type. Use the <a href="#">Terminal Descriptions</a> section to determine if your sensor is compatible with a sensor port.
Unit Type	Choose temperature, pressure, voltage, current or percentage based on the sensor. This defines what unit of measurement will be displayed on the front panel (°F, psi, V, A, %).

The following example outlines the steps for creating a custom sensor table:

1. Navigate to the sensor input that will be using your custom sensor table.
2. Select a Name, Input Type and Unit Type for the controller (Definitions in table above).
3. Click the check box next to 'Build Table' (Image Step 1).
4. From the 'Sender' drop down menu, select 'Custom' (Image Step 2).
5. Click the 'Edit' button next to the drop down menu (Image Step 3).
6. Enter the sensor values. Once entered, click Apply then OK.

**Sender Table Utility**

	Ohms	F
1	491	129
2	406	140.1
3	330	149.2
4	263	160
5	202	175
6	147	189.7
7	96	221
8	49	275
9	7	330
10		

Buttons: Apply, Ok, Cancel

## 5.6 Timers

The controller has an internal clock which is used not only to keep time, but to ensure programed events happen at the correct times. The following sections are used to configure settings associated with timing functions.



**NOTE:** The controller has an on-board backup battery to keep time even when main power is not supplied to the unit. This battery has an unpowered (no main power) lifetime of approximately five years.

### 5.6.1 Engine Logic

The following settings determine how the controller starts and stops the engine. It gives the user the functionality to add delays and timers to the sequences. Most of the settings have a switched output associated with them that must be set in the [Switched Outputs](#) settings.



**NOTE:** Setting a timer's value to 0 seconds will disable the timer. Example: If Delay to Start is set to 0 seconds, the controller will not perform a Delay to Start when starting the engine.

Timers > Engine Logic:

Name	Range	Default	Description
Delay to Start	0 ~ 90 seconds	0 s	Amount of time to delay the starting of the engine after receiving a command to start.
DTS Manual Run (Delay to Start on Manual Run)	Disable Delay or Enable Delay	Enable Delay	Determines if the the Delay to Start timer is used when the front panel RUN button is used to start the engine.
<a href="#">Preheat Mode</a>	Preheat Timer Switched Input J1939	Preheat Timer	Determines the method used to control enabling the glowplug output. See the <a href="#">Preheat Mode</a> section for more information.
Preheat Time	0 ~ 1200 seconds 0 ~ 90 in firmware versions below 1.33.	0 s	Amount of time the <a href="#">Glowplug output</a> is active before cranking the engine. Used on diesel engines to warm the engine before cranking.
Crank Time	3 ~ 30 seconds	10 s	Amount of time the <a href="#">Crank output</a> is active before going to crank rest. This timer immediately expires upon successful cranking.
Midheat Time	0 ~ 90 seconds	0 s	Keeps <a href="#">Glowplug output</a> turned on while cranking but not during crank rest. Output will turn off upon crank failure, crank success or midheat time expiration.
Crank Rest Time	1 ~ 90 seconds	15 s	Amount of time to delay between each attempt to start the engine.
Crank Attempts	1 ~ 20	3	Number of attempts to start the engine before going to an overcrank failure.
Fuel In Rest (Fuel Crank Rest)	Fuel ON or Fuel OFF	Fuel ON	Determines if the fuel output stays on during the crank rest time.
RPM Disconnect	100 ~ 2000 rpm	650 rpm	Speed at which controller determines the engine has started successfully and turns off the <a href="#">Crank output</a> .
Postheat Time	0 ~ 90 seconds	0 s	Amount of time the <a href="#">Glowplug output</a> remains on after crank success and the engine is running.
False Restart (Restart on False Start)	Enable false start (engine stall) detection. Refer to the <a href="#">False Restart</a> section.		
False Check (False Restart Detect Time)			
Warmup Time	0 ~ 600 s in 5 s increments	0 s	After successful cranking, engine delays this amount of time before turning on the <a href="#">Warmup output</a> . This allows the engine to warm up before applying any load to it. The output will turn off when the controller enters the Cooldown Delay.
<a href="#">OFF Button Function</a>	Cooldown Shutdown Force Cooldown	Shutdown	The function the OFF button on the front panel performs while engine is running. See the <a href="#">OFF Button Function</a> section for more information.
Cooldown Time	0 ~ 6000 s in 5 s increments	0 s	Amount of time to cool down the engine after a stop command has been received. During this time the <a href="#">Warmup output</a> turns off and the

Name	Range	Default	Description
			<u>Cooldown output</u> turns on. If another start command is received during cool down, the controller will return to running mode.
ETS On Duration (Energize to Stop)	0 ~ 30 seconds	0 s	Amount of time the <u>Energize to Stop (ETS) output</u> is on after the engine has shut down. Time must be greater than 0 seconds for the Energize to Stop function to work.  As of TG350/TG410 version 1.88 the OFF button is disabled during ETS to prevent possible issues with the engine failing to shutdown.  If controller still detects speed (RPM) above 600 RPM in the last two seconds, it goes to a ' <u>Failed to Stop</u> ' failure.
Warm-up Idle	Idle options. See the <a href="#">Idle</a> section for more information.		
Idle Settings			
Cooldown Idle			
Auto Idle Link			

### 5.6.1.1 Preheat Mode

The controller has the ability to control the length of the preheat time through 3 different methods. The table below describes each method:

Preheat Mode Setting (Timers > Engine Logic menu)

Mode	Description
Preheat Timer	This mode uses the Preheat Time setting in the Engine Logic menu.
Switched Input	This mode uses a switched input set to 'ECM Preheat' to determine when to exit preheat.  The preheat time (in <a href="#">Engine Logic</a> ) must be set to a minimum of 5 seconds for this input to work. If the switched input is or becomes active when the preheat timer is counting down the controller displays 'ECM Preheating' on the screen after the preheat counter has finished its countdown. Cranking begins when the 'ECM Preheat' switched input is no longer active.
J1939	This mode uses commands sent from the ECM over J1939 to decide when to exit preheat.



**NOTE:** During preheat the Glowplug switched output is on (it needs to be set to a switched output -- see [Switched Outputs](#)).

### 5.6.1.2 False Restart

The false restart feature is used to monitor and recover from unsuccessful crank attempts where the speed did go above the crank disconnect and the controller is in the RUN mode. For example the engine might have stalled shortly after cranking.

False Restart settings (under Timers > Engine Logic menu)

Name	Range	Default	Description
False Restart (Restart on False Start)	Enable or Disable	Disable	Determines if the controller will monitor for false starts and attempt a restart. Controller will only attempt restarting the engine as many times as determined by Crank Attempts.
False Check (False Restart Detect Time)	5 ~ 30 sec in 1 second intervals	8 s	Amount of time after successful cranking to monitor for a false restart. A false restart is defined as the speed dropping below 250 RPM for 2 seconds. If this time expires and the engines stalls out, the controller will not attempt a restart.  This time starts from crank success.

Tip: It takes up to 2 seconds for the false restart to be triggered. In addition it takes time for the engine speed to drop below 250RPM. These should be measured and added to the desired False Check setting.

For example when the speed is disconnected it takes approximately 2.5 s for the speed sensing to record 0 RPM when the speed sensing is set to a magnetic input at a speed of 3200Hz/1800RPM. This is 4.5 s including the 2 s for the false restart delay. So if the desired monitoring period is 10 s, the False Check setting should be set to 15 s.

#### 5.6.1.3 OFF Button Function

The OFF button on the front panel of the controller can be configured to function in 3 different ways while the engine is running. The table below describes each of these functions:

Function	Description
Cooldown	This function causes the controller to go into cooldown. Pressing the OFF button again will cause the engine to shut down.
Shutdown	This function bypasses Cooldown and causes the engine to shut down.
Force Cooldown	This function causes the controller to activate the cooldown process. Pressing the OFF button will have no affect as the controller is forcing the engine to perform a full cool down.



**WARNING:** If the controller receives a command to start from the remote start or front panel run button while in Cooldown, it will leave the Cooldown mode and go back to Running mode.

#### 5.6.1.4 Idle

Controller ignores under speed, voltage and frequency warnings and failures when active. If using J1939, the controller will broadcast TSC1 as the Idle Speed parameter found in the [Engine Speed](#) section.

This section explains the general idle functionality.

There are three ways to use idle:

1. [Warmup Idle](#) -- Automatically enter the idle mode during warmup for a period of time before going to rated speed. See [Warmup Idle](#).
2. [Cool down Idle](#) -- Idle automatically during cool down. See below.
3. [Idle Switched Input](#) -- Idle whenever this switched input is active. See the Idle Mode function under [Switched Inputs](#).

Name	Parent Menu	Range	Default	Description
Warmup Idle	Timers > Engine Logic	Disable Warm-up Timer Oil Temp. Engine Temp.	Refer to the <a href="#">Warmup Idle</a> section.	
Idle Settings	Timers > Engine Logic	[Menu]		
Cooldown Idle	Timers > Engine Logic	Disable Enable	Disable	Idle during cooldown.
Auto Idle Link	Timers > Engine Logic	Disable, Breaker Trip	Disable	If set to breaker trip, the breaker trip will be activated whenever the controller is in the Idle mode. The breaker trip will be turned off when Idle mode is exited if it was not in the latched state.  If the user delaches the breaker trip output while auto idle is active the breaker trip will turn off for one second and then turn back on.

#### Idle Switched Output

A switched output can be set to Idle to turn on whenever Idle mode is entered. This is useful for electronic governors that have an idle input to tell the governor to run the engine at idle speed. Note that the switched outputs are meant to drive relays so a relay must be installed to do the logic to the governor.

##### 5.6.1.4.1 Warmup Idle

This section explains the Warmup Idle functionality.

The warmup idle is used to run the engine at a reduced speed at engine start.

Name	Parent Menu	Range	Defaults	Description
Warm-up Idle	Timers > Engine Logic	Disable Warm-up Timer Oil Temp. Engine Temp.	Disable	If enabled the engine is placed in Idle mode during the warm-up period.  <a href="#">Warm-up Timer</a> -- The engine idles during the duration of the warm-up timer countdown. <a href="#">Oil Temp.</a> -- The oil temperature over J1939 is used to determine the extent of the warm-up / Idle period. <a href="#">Engine Temp.</a> -- Same as Oil Temp. but the engine temperature is used. The engine temperature can come locally or from J1939.  The oil temp and engine temp selections use the Debounce, Low Point, and High Point settings below.
Debounce	Timers > Engine Logic > Idle Settings	1 to 10 s, 1s increments	10 s	(Warm-up Idle) If the temperature remains between the "Low Point" and "High Point" settings for this time exit the warm-up / idle.
Low Point	Timers > Engine Logic > Idle Settings	1 to 180 °F, 1°F increments	32 F	(Warm-up Idle) Continue to idle when the temperature is below this setting. Ignore the Debounce.



Name	Parent Menu	Range	Defaults	Description
High Point	Timers > Engine Logic > Idle Settings	1 to 180 °F, 1°F increments	50 F	(Warm-up Idle) Always exit idle when the temperature is above this setting.

#### 5.6.1.4.2 Remote Start Inhibit In Idle

Use this feature to prevent start up when the Idle mode switch is active.

Settings (Other Config > Idle Inhibit, in the Configuration Software these are under the switched inputs when the idle input is enabled.)

Name	Parent Menu	Range	Default	Description
Remote Start (Start / Stop Switched Input Inhibit)	Other Config > Idle Inhibit	No Inhibit Inhibit	No Inhibit	Prevent the remote start switch input from starting the engine when the idle switch is active.
Aux Start (Aux 1,2,3,4 Sensor Autostart Inhibit)	Other Config > Idle Inhibit	No Inhibit Inhibit	No Inhibit	Prevent Auxiliary 1, 2, 3, and 4 sensors autostart feature from starting the engine when the idle switch is active.

If the engine is in the IDLE mode because of the [Warmup Idle](#) feature, the remote start (start/stop) and auxiliary sensors autostart can still start the engine.

This prevents starting when the Idle switch is active in the AUTO mode. This will also shutdown the engine if the idle switched input is activated when the controller is in the delay-to-start, preheat, cranking, and crank reset states. The main purpose is to prevent a remote start if the idle switch was accidentally left on.

## 5.6.2 Schedulers


### 5.6.2.1 Exerciser

The Exerciser function is used to start and run the engine periodically. The following settings configure the Exerciser function.

#### Exerciser Settings (in Timers menu)

Name	Range	Default	Description
Enable	Enable ~ Disable	Disable	Enables the exerciser feature.
Delays -> Pre-Alarm	1 ~ 20 minutes	5 min	Amount of time to display a warning before starting the engine.
Delays -> Run Time	10 ~ 1500 minutes	30 min	Amount of time to run the engine.
Schedule -> Start Date	1 ~ 31	8	The day of the month for the first exerciser run. This setting is only used to set the first exerciser run. All subsequent exerciser runs use the Repeat Days setting to determine when they should run.  If the date and time selected is already in the past for the current month then the exerciser will be started on the next month of the given date. Also if the date is not yet in the past but the current month does not have that date (e.g. February 21 and a date of 31 is selected) the exerciser will run on the next month to have that date (e.g. 31st of March).
Schedule -> Start Hour	0 ~ 23	12	The time of day for the exerciser run. If the "Pre-Alarm" setting above is non-zero then this setting indicates when the pre-alarm warning countdown will begin. The controller will start after the pre-alarm countdown is finished.
Schedule -> Repeat Days	1 ~ 28 days	14	Number of days between each exerciser cycle. This setting is applied to all subsequent exerciser starts after the first start.

#### Exerciser Sequence



If the controller is in the OFF mode, if the emergency stop is activated, or if the start inhibit is active then the exerciser will not run. The event, "Bypass Exerciser", will be logged in the event log and the exerciser will run again at the next scheduled time as determined by the "Repeat Days" setting.

### 5.6.2.2 Weekly Scheduler

The weekly scheduler allows up to 16 unique weekly exercise times to be created. By default all schedulers are disabled.

Timers > Week Scheduler:

Name	Range	Description
Weekday	Sunday ~ Saturday	The day of the week the exercise will take place on.
Start time	24 hour clock in 1 minute increments	When the exercise should start on a give day. At the selected time a one minute prealarm is displayed on the LCD screen. The controller starts after this one minute period.
Run time	10 ~ 1440 min in 1 min increments	The duration of the exercise run period. Up to one day.

When entering the Week Scheduler menu there will be 16 sub menu items each corresponding to one of the 16 weekly exercise times. If disabled the entry will have dashed lines: "--- --:-- -----". If enabled the day of week, start time, and duration will be displayed for the menu. Press enter will enter the sub menu for that exerciser time.

It is recommended to use the RapidCore Configuration Software to enter the times as this provides a much more convenient interface especially if daily exercise times are wanted.

### 5.6.2.3 Long Time Run

The Long Time Run counter can be used to shutdown the controller after a very long period of time. This is useful for remote primary power applications where the user wants to divide run time between two generators. When the countdown expires the controller will shutdown. Long Time Run is only active if the generator was started manually (i.e. by pressing the front Run button).

Timers > Long Time Run:

Name	Range	Default	Description
Start Trigger	Disable or Manual Start	Disable	Set to "Manual Start" to enable the Long Time Run feature.
Run Duration	1 ~ 5000 hours in 1 hour increment	1 hour	The amount of time to run before shutting down.

## 5.6.3 Maintenance

The controller has the ability to count down the time between scheduled maintenance events. Once maintenance is required, the controller will alert the operator via the LCD screen and a switched output (if enabled) wired to a lamp / horn / buzzer. The following settings are used to configure the maintenance timer.

(Timers > Maintenance)

Name	Range	Default	Description
Reset Counter	Yes or No	-----	Once the maintenance count interval expires, use this to reset the time and turn off the switched output (if enabled). Select Yes to reset the counter and exit the menu. Select No to exit the menu without resetting the counter.
Enable Counter	Enable or Disable	Disable	Enables or disables the maintenance function.
Count Interval	10 ~ 9990 hours in 5 hour increments	1000 hours	Determines the number of hours between required maintenance. A switched output can be configured to turn on once the count interval expires.

To determine the amount of time until the next scheduled maintenance, follow these menu steps:

*Main Menu -> Device Info. -> Maintenance*

Maintenance counter is disabled if '-----' is displayed. A negative number indicates the amount of time since maintenance timer expired.

**NOTE:** The maintenance timer displays "Service Required" when this time expires. This message is only displayed the next time the controller enters the RUN mode. If the timer expires when the controller is in the RUN mode the message is not displayed.

## 5.7 AC Monitor

The controller has the ability to monitor AC voltage from a generator. The following sections are used to configure settings associated with AC monitoring.

### 5.7.1 Generator Voltage

The following settings are used to configure the controller's response to voltage measurements.

(AC Monitor > Genset Voltage menu)

Name	Range	Default	Description
Voltage Source	Disable 2-Wire Single 3-Wire Single 3-Wire 3-Phase 4-Wire 3-Phase 4-Wire Delta Auto Selection	3-Wire Single	The wiring configuration of the generator. Disable will disable AC voltage and AC frequency sensing and display.  <u>2-Wire Single:</u> One 120VAC L-N. Use phase A. <u>3-Wire Single:</u> 120/240VAC systems. Use phases A and B. <u>3-Wire 3-Phase:</u> Three phase delta without a ground. <u>4-Wire 3-Phase:</u> Three phase Wye system. Center taped ground. <u>4-Wire Delta:</u> Delta with a ground. The high leg is phase B. For example if A-N and C-N read 120VAC then B-N will read 208VAC.  Selecting Auto Selection will use the <a href="#">Voltage Select</a> switched inputs to determine the wiring configuration.  This setting also enables the <a href="#">AC Frequency</a> monitoring and display.
Scaling Factor	0.500 ~ 2.500 in 0.001 increments	1.000	The gain to apply to the AC voltage that is read at the controller. See below for more information.
Nominal Volts	50 ~ 800 VAC* in 1 VAC increments	240 VAC	Generator line-to-line voltage output when operating under normal running conditions.
Auto Nominal > 1Ph 3-Wire (1-Phase 3-Wire)	50 ~ 800 VAC* in 1 VAC increments	240 VAC	Nominal Volts when using the <a href="#">Voltage Select</a> inputs.
Auto Nominal > 3-Phase (1)	50 ~ 800 VAC* in 1 VAC increments	208 VAC	
Auto Nominal > 3-Phase (2)	50 ~ 800 VAC* in 1 VAC increments	480 VAC	
Auto Nominal > 3-Phase (3)	50 ~ 800 VAC* in 1 VAC increments	600 VAC	
Auto Scaling > 1Ph 3-Wire (1-Phase 3-Wire)	0.500 ~ 2.500 in 0.001 increments	1.000	Scaling Factor when using the <a href="#">Voltage Select</a> inputs.
Auto Scaling > 3-Phase (1)	0.500 ~ 2.500 in 0.001 increments	1.000	
Auto Scaling > 3-Phase (2)	0.500 ~ 2.500 in 0.001 increments	1.000	
Auto Scaling > 3-Phase (3)	0.500 ~ 2.500 in 0.001 increments	1.000	
Auto Single	A-C Phase A-B Phase	A-B Phase	For 1-Phase 3-Wire when using the <a href="#">Voltage Select</a> inputs. This determines which phases the single phase voltage is read from.
Setpoints > Low Warn	50 ~ 99 % in 1 % increments	90 %	Reading at which a warning occurs.
Setpoints > Low Fail	50 ~ 99 % in 1 % increments	85 %	Reading at which a failure occurs.

Name	Range	Default	Description
Setpoints > High Warn	101 ~ 150 % in 1 % increments	110 %	Reading at which a warning occurs.
Setpoints > High Fail	101 ~ 150 % in 1 % increments	115 %	Reading at which a failure occurs.



**\*NOTE:** 800 VAC applies to software logic only. Do not exceed 600 VAC on the AC Voltage terminals including during over voltage warning and failure conditions.

**Application Note: Scaling Factor**

The scaling factor setting can be used to calibrate the AC voltage if there are discrepancies between the reading and the actual value. It can also be used if transformers are used to step up / down the voltage. The scaling factor applies to all phases in a system.

Example: The voltage source is a 3-Wire 3-Phase system with a nominal voltage of 208 VAC. The controller is reading 206.3 VAC but a calibrated multimeter gives 208.3 VAC. Use the formula below to determine the scaling factor.

1. Scaling Factor = Multimeter Reading / Controller Reading
2. Scaling Factor = 208.4 VAC / 206.3 VAC
3. Scaling Factor = 1.010

### 5.7.1.1 AC Voltage Select

The controller has the ability to automatically change its AC sensing (voltage and current) and display configuration through the use of switched inputs. When using voltage select, the controller will continue to monitor the inputs for 10 seconds after crank success. Once that time expires, the controller will then display the selected voltage configuration.

The following must be set:

1. Two switched inputs (Switched I/O > Switched IN X > Function ) must be set to the *Volt Select 1* and *Volt Select 2* switch input functions.
2. AC Monitor > Genset Voltage > Voltage Source must be set to *Auto Selection*. Rapid Configuration Software note: this option will not appear unless step one is performed.

The table below shows the relation between the switched inputs status and the voltage configuration.

Volt Select 1 Input	Volt Select 2 Input	Voltage Configuration
Inactive	Inactive	3-Wire Single Phase
Active	Inactive	3-Phase (1)
Inactive	Active	3-Phase (2)
Active	Active	3-Phase (3)



**NOTE:** Both *Volt Select 1* and *Volt Select 2* must be assigned to switched inputs. Otherwise the voltage sensing will be disabled.

The below settings must be set. All except "Auto Single" are menus that contain four settings corresponding to the Volt Select 1 / Volt Select 2 inputs above.

Name	Volt Select 2 Input
Genset Voltage > Auto Nominal	These settings corresponds to the "Nominal Volts" setting under the AC Monitor > Genset Voltage menu.
Genset Voltage > Auto Scaling	These settings corresponds to the "Scaling Factor" setting under the AC Monitor > Genset Voltage menu.
Genset Voltage > Auto Single	Only applies when voltage source is set to 1-Phase 3-Wire. This determines which phases the single phase voltage is read from: A-C or A-B.
Genset Current > Auto Rated	These settings corresponds to the "Rated Amps" setting under the AC Monitor > Genset Current menu.
Genset Current > Auto Scaling	These settings corresponds to the "Scaling Factor" setting under the AC Monitor > Genset Current menu.

## 5.7.2 Generator Frequency

Generator AC frequency display on the controller is enabled when the [Voltage Source](#) is not set to Disable.

The following settings are used to configure the controller's responses to frequency measurements.

**Frequency Settings** (in AC Monitor > Genset Freq.)

Name	Range	Default	Description
Freq. Source	50Hz System (50Hz) 60Hz System (60Hz) Auto Selection	60Hz System	This is the wiring configuration of the generator. Selecting Auto Selection will use the <a href="#">Frequency Select</a> input to determine which frequency is used.  This setting is used by the below setpoints. It does not affect the display of AC Frequency.
Setpoints > Low Warn (Under-Frequency Warning)	Disable, 20 ~ 99 % in 1 % increments	90 %	Reading at which a warning occurs.
Setpoints > Low Fail (Under-Frequency Failure)	Disable, 20 ~ 99 % in 1 % increments	85 %	Reading at which a failure occurs.

Name	Range	Default	Description
Setpoints > High Warn (Over-Frequency Warning)	Disable, 101 ~ 150 % in 1 % increments	110 %	Reading at which a warning occurs.
Setpoints > High Fail (Over-Frequency Failure)	Disable, 101 ~ 150 % in 1 % increments	115 %	Reading at which a failure occurs.

### 5.7.2.1 RPM / Frequency Select

The controller has the ability to change between Primary RPM / 60Hz and Secondary RPM / 50Hz through the use of a switched input.

The following settings must be set in order for this feature to function:

- Switched I/O > Switched In A/B/C/D/E > Function > RPM Switch (Primary RPM / 60Hz - Secondary RPM / 50Hz Select). The switched input is only monitored before a start signal has been received. Once a start signal has been received changing the status of the switched input will have no effect.
- AC Monitor > Genset Freq. > Freq. Source > Auto Selection
- Sensors > Engine Speed > RPM Switch > Primary (Primary RPM / 60Hz)
- Sensors > Engine Speed > RPM Switch > Secondary (Secondary RPM / 50Hz)

The table below shows the correspondence between the switched input status and the RPM / Frequency.

Switched Input	Speed / Frequency
Inactive	Primary RPM / 60Hz
Active	Secondary RPM / 50Hz



**NOTE:** If enabled, the J1939 TSC1 PGN will be broadcasted according to the selected speed. Otherwise only the warning and failure setpoints are affected by this function.

### 5.7.3 Generator Current

The following settings are used to configure the controller response to current measurements.

AC Monitor > Genset Current:

Name	Range	Default	Description
Current Source	Enable ~ Disable	Enable	Enables or disables current metering.
Turns Ratio	5 ~ 5000 A : 5 A in 5 A increments	100 A : 5A	The turns ratio of the current transformers.
Scaling Factor	0.500 ~ 1.250 in 0.001 increments	1.000	Scaling factor at which the voltage is read into the controller. See below for more information.
Rated Amps	5 ~ 5000 A in 1 A increments	100 A	Maximum current draw the generator can provide when operating under normal running conditions.
Auto Rated > 1Ph 3-Wire	5 ~ 5000 A in 1 A increments	100 A	Rated Amps when using the <a href="#">Voltage Select</a> inputs.
Auto Rated > 3-Phase (1)	5 ~ 5000 A in 1 A increments	100 A	
Auto Rated > 3-Phase (2)	5 ~ 5000 A in 1 A increments	100 A	
Auto Rated > 3-Phase (3)	5 ~ 5000 A in 1 A increments	100A	
Auto Scaling > 1Ph 3-Wire	0.500 ~ 2.250	1.000	Scaling Factor when using the <a href="#">Voltage Select</a> inputs.
Auto Scaling > 3-Phase (1)	0.500 ~ 2.250	1.000	
Auto Scaling > 3-Phase (2)	0.500 ~ 2.250	1.000	
Auto Scaling > 3-Phase (3)	0.500 ~ 2.250	1.000	
Dummy Load	[Menu]	See <a href="#">Dummy Load</a> .	



AC Monitor > O.C. Protection:

Name	Range	Default	Description
Basic Alarm	[Menu]	See <a href="#">Basic Alarms</a> .	
IDMT Protect	Disable Breaker Trip Shutdown Trip	See <a href="#">IDMT</a> .	
IDMT Settings	[Menu]		
Imbalance Mode	Disable Breaker Trip Shutdown Trip	See <a href="#">Load Imbalance</a> .	
Imbalance Set	[Menu]		
Break Trip Fail	Disable Enable	Disable	Shuts down the generator if the generator circuit breaker fails to trip.  If the <a href="#">Breaker Trip</a> switched output is active - due to <a href="#">IDMT</a> or <a href="#">Load Imbalance</a> - and if after 10s the measured generator current is still above 10% of the Rated Current the generator will shut down.

### 5.7.3.1 Basic Alarms

The controller can give a warning and/or shutdown on over current. If [IDMT](#) is enabled then it overrides the High Failure shutdown but the warning is still active.

AC Monitor > O.C. Protection > Basic Alarm:



Name	Range	Default	Description
High Warn	Disable, 1 ~ 125 % in 1 % increments	110 %	Reading at which a warning occurs.
High Fail	Disable, 1 ~ 125 % in 1 % increments	115 %	Reading at which a failure occurs.

Percentages are based on the Rated Amps setting. The warning and failure setpoints apply to each phase separately and not to the sum of the phases.

### 5.7.3.2 IDMT

Sets an inverse time trip curve for over-current. When set this overrides the [Over Current Failure](#).

AC Monitor > O.C. Protection:

Name	Range	Default	Description
IDMT Protect	Disable Breaker Trip Shutdown Trip	Disable	<b>Disable:</b> Disables the IDMT feature.  <b>Breaker Trip:</b> If IDMT is active the <a href="#">Breaker Trip</a> switched output is activated to switch off the main generator breaker. This is a latching feature. The operator must press the  and  keys to reset the feature.  <b>Shutdown Trip:</b> shuts down the engine.
IDMT Settings > TDS Const (Time Dial Setting)	0.1 ~ 30 in 0.1 increments	0.3	Sets the slope of the IDMT curve. This controls the sensitivity of the trip to over current.
IDMT Settings > IDMT Reset	1 ~ 600 s in 1 s	200 s	How long the current must drop and stay below the rated current to reset the IDMT.

Name	Range	Default	Description
	increments		

The equation for the IDMT is given as:

$$(t_r)_m = \frac{TDS * 13.5}{\frac{I}{I_s} - 1}$$

Where,

**TDS** is the time dial setting above.

**I<sub>s</sub>** is the **Rated Current** (A).

**I** is the actual current measured by the controller (A).

**(t<sub>r</sub>)<sub>m</sub>** is the trip time in seconds.

For example with a Rated Current of 100A and a TDS of 0.1 the IDMT will trigger in:

0.15s if the actual generator current is 1000A.



1.35s if the actual generator current is 200A.

6.75s if the actual generator current is 120A.

### 5.7.3.3 Load Imbalance

Load imbalance provides protection against differences in phase currents.

AC Monitor > O.C. Protection:

Name	Range	Default	Description
Imbalance Mode	Disable Trip Only Shutdown Trip	Disable	<p><b>Disable:</b> Disables the Load Imbalance feature.</p> <p><b>Breaker Trip:</b> If Load Imbalance is active the <b>Breaker Trip</b> switched output is activated to switch off the main generator breaker. This is a latching feature.</p> <p>The operator must press the  and  keys to reset the latch.</p> <p><b>Shutdown Trip:</b> shuts down the engine.</p>
Imbalance Set > Imbalance	1 ~ 200 % in 1 % increments	10 %	The percentage of rated current that any phase must exceed the other phases by to trigger a load imbalance.
Imbalance Set > Debounce	1 ~ 600 s in 1 % increments	10 s	The length of time to allow an imbalance before triggering (trip, shutdown).

The load imbalance formula is given as:

For three phase:

$$\max\{|I_A - I_B|, |I_A - I_C|, |I_B - I_C|\} > \text{Rated Amps} \times \text{Phase\_Imbalance\_Threshold}(\%)$$

For single phase:

$$|I_1 - I_2| > \text{Rated Amps} \times \text{Phase\_Imbalance\_Threshold}(\%)$$

Where,

**I<sub>A</sub>**, **I<sub>B</sub>**, and **I<sub>C</sub>** are the actual current measured by the controller.

Note: Phase Imbalance is the same as load imbalance.

#### 5.7.3.4 Dummy Load

The dummy load feature can be enabled to prevent wet stacking.

AC Monitor > Genset Current > Dummy Load:

Name	Range	Default	Description
Bypass Time	Disabled, 1 ~ 120 s in 1 s intervals	Disabled	The amount of time to delay before applying the dummy load.
Load On	Disabled, 1 ~ 500 A in 1 A increments	Disabled	The threshold below which the dummy load is applied. There is a 4s debounce time. The bypass time must expire before the load is applied. All phases must drop below this threshold to trigger dummy load.
Load Off	Disabled, 1 ~ 500 A in 1 A increments	Disabled	The threshold above which the dummy load is removed. Dummy load is turned off if one phase rises above this threshold.

One of the [switched outputs](#) must also be set to dummy load. The output is only turned on when the engine is running.

#### 5.7.3.5 EPS Supplying Load

The EPS (Emergency Power System) Supplying load sets a flag in modbus register 40006 to indicate to the DYNAGEN RA400 remote annunciator that the generator is actively supplying power. If this flag is set the RA400 will light it's EPS Supplying Load indicator. This is used to meet NFPA110 requirements.

If the actual current measured on any one phase of the generator is above 5% of the AC over current warning set point then the EPS Supplying load flag is set. For more information on this register refer to the TOUGH Series modbus manual or RA400 manual.

## 5.8 Communications

The controller has the ability to communicate with other systems over communication buses. The following sections relate to settings associated with communications.

### 5.8.1 CAN Bus (J1939)

This page gives a very short overview of J1939 support (electronic engines). For detailed information about J1939 and all related settings please refer to the J1939 Reference Manual. The manual can be found at [www.dynagen.com/support](http://www.dynagen.com/support).

Name	Range	Default	Description
ECM Model	Generic J1939 John Deere JDEC Volvo EMS  This is not a complete list. See the J1939 User Manual for the full list.	Generic J1939	Choose one of the compatible ECM modules from the list.
ECM Communication Failure	Enable ~ Disable	Disable	If no CAN messages are received for more than 6 seconds, the controller shuts down the engine.
DTC Display	Disable Global Enable Running Enable	Disable	Enables or disables active fault messages (DM1) monitoring.
Active DTC Log	Enable ~ Disable	Disable	Enables or disables the storing of active faults (DM1).
Read Stored DTC	Enable ~ Disable	Disable	Enables or disables the ability to request stored fault codes from the ECM (DM2).

Name	Range	Default	Description
Auto Power ECM	Enable ~ Disable	Disable	When enabled, the fuel relay is enabled in Auto mode so that the ECM is already booted up and initialized before the user decides to start the engine.
ECM Power Delay	5 ~ 30 s in 1 s increments	10 s	Used in conjunction with Auto Power ECM. When the engine shuts down, the controller waits for the time specified by the ECM Power Delay before turning on the fuel relay. This prevents unwanted start ups due to the engine not being completely shut down.
Cummins PGNs	Disable or Sending Enable	Sending Enable	Enables or disables the broadcasting of PGNs required by some Cummins engines.
SPN Conversion	Version 1 Version 2 Version 3	Version 3	Select the SPN conversion method.
EMS2B Frequency Select	Primary Secondary	Primary	For Volvo EMS2B Engine Control Modules only.
EMS2B Accelerator Pedal	40.0 ~ 60.0 % in 0.1 % increments	50.0 %	For Volvo EMS2B Engine Control Modules only.

## 5.8.2 Modbus (RS485)

The Modbus functionality on the controller provides interface ability to PLCs, SCADA and building management systems. For detailed information about the Modbus registers and their interpretations please use the Modbus Reference Manual. The manual can be found at [www.dynagen.ca/support](http://www.dynagen.ca/support).

It uses the Modbus RTU communication protocol and is configured as a slave only.

Name	Range / Values	Default	Description
Device Address	1 ~ 247 in 1 increments	1	The device address of the controller.
Baud Rate (BPS)	9600, 19200, 38400, 57400	9600	The speed at which the controller (slave) communicates with the master.

## 5.9 Other Config

This section contains miscellaneous settings.

### 5.9.1 Password

A password is required to change certain settings. The Password menu is used to change this password and control if and when the user is prompted for a password.

Other Config > Passcode:

Name	Range	Default	Description
Bypass	Disable or Enable	Disable	If enabled a password is not required to change settings.
Timeout	0 ~ 120 minutes in 1 minute increments	10 min	How long after the password is entered before the user is required to enter it again.  The timeout is implemented as a simple countdown timer. The following apply: <ul style="list-style-type: none"> <li>If the bypass time is changed this new bypass time will not be loaded until the countdown timer has expired and the user enters the password.</li> <li>The countdown timer is stored in non-volatile memory and is "paused" when the controller is powered off. The counter will resume when the controller is powered on again.</li> <li>Any button press in the menu will reset the timer.</li> </ul>
Passcode	0000 ~ 9999	0000	The four numeric digits that make up the password.

### 5.9.2 Settings Name / ID

If storing settings from the RapidCore Configuration Software a custom name can be entered to allow users to determine the settings that are stored in the controller. This custom name, called "Configuration Name" (ID in the controller) is found under Options in the settings tab of the Configuration Software. There is no controller menu to set this ID. It can be up to 12 characters long.

The Configuration Name can be viewed in the Device Info > About TG410/TG350 menu. It is labeled ID.

### 5.9.3 Process Control

**Note: The process control is only enabled in the TE Series 1.91 and above.**

The Process Control feature has two different control methods: Main-In and Main-Out. The Main-In maintains a reservoir/pressure level by controlling the flow of fluid/gas into the reservoir/tank. The Main-Out maintains a reservoir/pressure level by controlling the flow of fluid/gas from the reservoir/tank. It does this by regulation the speed of the engine over the J1939 CAN bus.

The process control feature takes over on an engine start once the engine has ramped up to the goal speed (after going through the idle and intermediate ramping).

The controller reads the sensor value from selected Auxiliary Sensor input (1~4) or Transducer Input (Aux 5), compares the input value with the set-point, and then, based on an algorithm, increments or decrements the speed (RPM) by a certain amount (controlled by the Gain and delay settings) to maintain the desired set-point outside of the dead-band area. Control pauses inside the dead-band area. If the sensor input goes beyond a minimum or maximum value, the algorithm will pause and the RPM will be maintained at a minimum or maximum value.

The algorithm is a fuzzy logic type control with a dead band and a minimum / maximum saturation. The user sets the aggressiveness of the control with the *Gain* setting and the response time of the control with the *Delay* setting.

(Front Panel: Other Config > Process Control menu, RapidCore: Pumping Applications > Closed Loop Control)

Name	Range	Default	Description
Closed Loop > System (Control Type)	Disabled Main-In (Maintain In) Main-Out (Maintain Out)	Disabled	Main-In controls the level when pumping fluid into a reservoir. Main-Out controls the level while pumping fluid out of the reservoir.
Closed Loop > Sensor In (Sensor Input)	AUX-1 AUX-2 AUX-3 AUX-4 AUX-5	Aux-5	The Auxiliary Sensor Input function that is providing feedback on the reservoir level. Aux-5 refers to the Transducer under the Application menu.
Closed Loop > Delay	1 ~ 30 s in 0.1 s increments	8.0 s	The sampling time of the control algorithm. This value must be tuned for each installation.
Closed Loop > Gain	1 ~ 30 in 0.1 increments	19.0	The amount to increment or decrement the RPM when the sensed value is outside of the dead-band. This number does not represent an actual RPM. A larger gain will generate a larger RPM change than a smaller gain for the same size error. This value must be tuned for each installation.
Setpoints > Main-In (Maintain In Setpoint)	1 ~ 900 in 0.1 increments	300.0	The level set-point to attempt to maintain. Only applies if System is set to In-Keep. This value takes on the units of the Aux sensor set in the Closed Loop > Sensor In menu.
Setpoints > Main-Out (Maintain Out Setpoint)	1 ~ 900 in 0.1 increments	500.0	The level set-point to attempt to maintain. Only applies if System is set to Out-Keep. This value takes on the units of the Aux sensor set in the Closed Loop > Sensor In menu.
Setpoints > Deadband+ (High Deadband)	1 ~ 30 in 0.1 increments	3.0	The high limit of the dead-band.
Setpoints > Deadband- (Low Deadband)	1 ~ 30 in 0.1 increments	3.0	The low limit of the dead-band.

Thresholds > High Edge (High Limit)	1 ~ 900, 0.1 increments	700.0	The high saturation. The maximum level at which the RPM control is fixed. This value takes on the units of the Aux sensor set in the Closed Loop > Sensor In menu.
Thresholds > Low Edge (Low Limit)	1 ~ 900, 0.1 increments	100.0	The low saturation. The minimum level at which the RPM control is fixed. This value takes on the units of the Aux sensor set in the Closed Loop > Sensor In menu.
Thresholds > Max RPM (Max Limit RPM)	500 ~ 4000 RPM in 1 RPM increments	3200 RPM	The fixed RPM that should be used when the level rises above the High Edge.
Thresholds > Min RPM (Low Limit RPM)	500 ~ 4000 RPM in 1 RPM increments	1000 RPM	The fixed RPM that should be used when the level falls below the Low Edge.

### 5.9.4 Pump System

This menu contains various settings related to pumping applications. It is used in conjunction with the Application menu. The application menu is the end user oriented menu which allows end user to make changes.

In the front panel the below settings are located under Other Config > Pump System.

In RapidCore:

1. The ramp settings are located under Sensors > Engine Speed > Speed Settings.
2. The float control and tank maximum settings are located under Pumping Applications.

Name	Range	Description
Run Button (Manual Run Button)	Run Only Run&Throttle	Controls when the user can manually adjust the engine speed when the controller is started by a manual run. "Run Only" means the speed can only be adjusted once the engine speed has reached the goal speed. "Run&Throttle" means the speed can be adjusted once the engine has reached idle.
Ramp Setting	Sub menu	-----
Ramp Setting > Goal Speed	500 ~ 4000 RPM in 1 RPM increments	The final speed after the speed ramping is finished.
Ramp Setting > Bump Speed	Disable, 0 ~ 500 RPM in 1 RPM increments	The maximum amount the user is allowed to adjust the speed.
Ramp Setting > Interm Speed (Intermediate Speed)	500 ~ 4000 RPM in 1 RPM increments	The speed between the idle and goal speeds.
Ramp Setting > Interm Delay (Intermediate Delay)	1 ~ 300 s in 1 s increments	The amount of time to remain at the intermediate speed.
Ramp Time	Sub menu	-----
Ramp Time > Dwell 1 (Idle to Intermediate)*	1 ~ 300 s in 1 s increments	The amount of time to ramp from the idle to intermediate speed.
Ramp Time > Dwell 2 (Intermediate to Rated)*	1 ~ 300 s in 1 s increments	The amount of time to ramp from the intermediate to goal speed.
Ramp Time > Dwell 3 (Rated to Idle)*	1 ~ 300 s in 1 s increments	The amount of time - in addition to the cooldown time - to ramp from the goal speed to the idle speed.
Float Control	Disable Fill Tank Empty Tank	Float control can autostart the engine if one of the switched input functions are set to the float function and is active.  For example for a single float system "Fill tank" will start the engine if float 1 switched input is inactive (open). "Empty Tank" will start the engine if "float 1" switched input is active (closed). Refer to the <a href="#">Autostart on Floats</a> section of the manual in the Application chapter.  Single / Dual Floats mode is set by the "Float Autostart" setting in the Application > Function menu.
Tank Maximum	Sub menu	These settings determine the maximum aux sensor value that is equivalent to a full tank. If the sensor value rises above these setpoints then the value displayed in the tank is clamped to these settings.

Name	Range	Description
Tank Maximum > Max %	Disable, 0.1 ~ 110.0 % in 0.1 % increments	Used by the <a href="#">Aux 5 (Transducer)</a> sender in the Application menu.
Tank Maximum > Max Psi	Disable, 0.1 ~ 110.0 % in 0.1 % increments	
Tank Maximum > Max Foot	Disable, 0.1 ~ 110.0 % in 0.1 % increments	
RPM Display	Blank AC Hertz Aux Sensor 1 Aux Sensor 2	This is a replication of the "RPM Display" setting in the Sensors > Engine Speed menu.
RPM Setting	Sub menu	These are a replication of the RPM Setting menu under the Sensors > Engine Speed menu.  The first three control the minimum and maximum that the engine speed to be adjusted to. The Tsc1 RPM/s setting controls the maximum rate at which the engine speed can be changed. These affect automatic and manual speed control and any other speed control features.
RPM Setting > Min Speed	500 ~ 4000 RPM in 1 RPM increments	
RPM Setting > Max Speed	500 ~ 4000 RPM in 1 RPM increments	
RPM Setting > Speed Bias	0 ~ 600 RPM in 1 RPM increments	
RPM Setting > Tsc1 RPM/s	Disable, 10 ~ 300 RPM/s in 10 RPM/s increments	

\* Note that the minimum ramp rate is 1.25RPM/s. If the speeds to ramp between and the ramp delay give a rpm/s below this then 1.25rpm/s will be used. For example a speed difference of 300RPM and a ramp time of 300s gives 1 RPM/s but 1.25RPM/s will be used instead giving a ramp time of 240s ( $300 \text{ RPM} \div 1.25 \text{ RPM/s} = 240\text{s}$ ).

## 6 Troubleshooting

If you are having issues with your controller, please refer to the table below for a solution before contacting technical support.

Issue	Solution
Engine starts but the crank output does not turn off	The controller is not receiving a speed signal. <ol style="list-style-type: none"> <li>1. Verify the Sensors -&gt; Engine Speed -&gt; Signal Source setting is set correctly.</li> <li>2. Verify the Timers -&gt; Engine Logic -&gt; RPM Disconnect setting is set correctly.</li> <li>3. Ensure the correct wiring to the controller. For magnetic pickup, Speed Sensing A and B terminals are used. For generator voltage, the AC voltage connections are used.</li> </ol>
Sensor always displays its lowest or highest value	The sensor could either be open (not connected) or shorted to ground. Verify your connections and ensure the correct sender table is loaded.
Sensor value acts erratic, bounces, or climbs on engine startup	This could be caused by: <ol style="list-style-type: none"> <li>1. Bad ground between sensor and controller. Check that there is a good ground between negative post on the battery and the battery negative terminal (J4-3) on the controller. Also check that the connection from the negative post on the battery to the sensor body is good; if not then add a grounding wire close to the sensor.</li> <li>2. The group strap is not sufficient AWG. Ensure the ground and power wiring can carry the large amperage for the starter motor and other equipment.</li> <li>3. If using a magnetic pickup sensor for speed sensing it might be generating noise. Use a shield twisted pair cable from the mag sensor to the controller. Refer to the typical wiring diagram on how to do this.</li> <li>4. Try twisted pair cable running both ground and the signal; ground near the sensor body. Try an isolated sensor (sensor has both a ground post and a signal post).</li> </ol>
Controller displays "Failure To Stop" on a shutdown.	Either set Energize to Stop under Timers to 0 seconds or increase it's duration. At the end of the Energize to Stop time the controller will detect if the engine speed is zero. If it is not it goes into a "Failure To Stop" failure.

DYNAGEN can be contacted by any of the methods below. Technical support is offered Monday - Friday, 8:00am - 4:00pm (EST). If you are unable to contact one of our engineers, please leave a message and they will return your call as soon as possible.

Type	Information
Website	<a href="http://www.dynagen.ca/support">www.dynagen.ca/support</a>
Email	<a href="mailto:support@dynagen.ca">support@dynagen.ca</a>
Phone Number	(902) 406-0133
Twitter	@DynaGenTech
Facebook	<a href="https://www.facebook.com/DYNAGEN">www.facebook.com/DYNAGEN</a>
Address	3 Spectacle Lake Drive, Unit B105 Dartmouth, NS B3B1W8, Canada