

Exhaust Wrap

The instructions below apply to
the following part number's.

<u>Part Number</u>	<u>Description</u>
HS-311025	Exhaust Wrap; 1" x 25'
HS-311050	Exhaust Wrap; 1" x 50'
HS-312025	Exhaust Wrap; 2" x 25'
HS-312050	Exhaust Wrap; 2" x 50'

Installation Instructions:

1. Wear safety glasses, gloves, and dust mask.
2. Wearing a long sleeve shirt is also recommended.
3. Keep in mind; wrapping manifolds, mufflers and exhaust pipes requires patience. Going slow and taking your time will help to make the wrap as tight as possible and that will hold the wrap on the pipe better and retain the most heat in the system.
4. Optional: Soak exhaust wrap in bucket of water. Soaking exhaust wrap can make installation easier and also reduce the amount of fibers.
5. It is important to start on side closest to exhaust port (closest to engine), wrapping down the system towards the exhaust tip.
6. Make an initial wrap around the pipe and secure end with a metal tie, hose clamp or safety wire.
7. After securing end, continue to wrap around pipe, using 1/4" to 1/2" overlap with each pass and keeping tension on the exhaust wrap.
8. Every 2 to 3 coils use your hands to tighten the wrap. If you soaked wrap, you'll see water dripping out. Getting the water out is not the purpose for this, tightening the wrap is.

PLEASE NOTE: Your exhaust wrap will smoke after installation, it will eventually stop. Smoke is a normal by product of the curing process; your wrap will not burst into flames.



www.davidsonsales.com
839 Bill France Blvd., Daytona Beach, FL 32117
Phone (386)274-2079 Phone (800)383-2078
Fax (386)274-2279 Fax (800)475-2279