

Note 1: A relay may be required for the remote start contacts. See ES52 manual for more details.