

Replacement Parts

For thermosiphon engine heaters
CB, CL Model

Model Number without Thermostat	Model Number with Thermostat see chart 2	Replacement Parts				
		Element	Tank	Box	Element O-ring	Mounting Brackets
CB115100-000	CB1151XX-200	RECB1151	RTB	RTBCB	TMM-OR	RTMMB
CB115800-000	CB1158XX-200	RECB1158	RTB	RTBCB	TMM-OR	RTMMB
CB115200-000	CB1152XX-200	RECB1152	RTB	RTBCB	TMM-OR	RTMMB
CB115700-000	CB1157XX-200	RECB1157	RTB	RTBCB	TMM-OR	RTMMB
CB115300-000	CB1153XX-200	RECB1153	RTB	RTBCB	TMM-OR	RTMMB
CB115400-000	CB1154XX-200	RECB1154	RTB	RTBCB	TMM-OR	RTMMB
CB120100-000	CB1201XX-200	RECB1201	RTB	RTBCB	TMM-OR	RTMMB
CB120800-000	CB1208XX-200	RECB1208	RTB	RTBCB	TMM-OR	RTMMB
CB120200-000	CB1202XX-200	RECB1202	RTB	RTBCB	TMM-OR	RTMMB
CB120300-000	CB1203XX-200	RECB1203	RTB	RTBCB	TMM-OR	RTMMB
CB120400-000	CB1204XX-200	RECB1204	RTB	RTBCB	TMM-OR	RTMMB
CB125100-000	CB1251XX-200	RECB1251	RTB	RTBCB	TMM-OR	RTMMB
CB125800-000	CB1258XX-200	RECB1258	RTB	RTBCB	TMM-OR	RTMMB
CB125200-000	CB1252XX-200	RECB1252	RTB	RTBCB	TMM-OR	RTMMB
CB125700-000	CB1257XX-200	RECB1257	RTB	RTBCB	TMM-OR	RTMMB
CB125300-000	CB1253XX-200	RECB1253	RTB	RTBCB	TMM-OR	RTMMB
CB125400-000	CB1254XX-200	RECB1254	RTB	RTBCB	TMM-OR	RTMMB
CL130100-100	CL1301XX-200	RECL1301-100	RTL	RTBCL-100	TML-OR	FK7
CL130800-100	CL1308XX-200	RECL1308-100	RTL	RTBCL-100	TML-OR	FK7
CL130200-100	CL1302XX-200	RECL1302-100	RTL	RTBCL-100	TML-OR	FK7
CL130700-100	CL1307XX-200	RECL1307-100	RTL	RTBCL-100	TML-OR	FK7
CL130300-100	CL1303XX-200	RECL1303-100	RTL	RTBCL-100	TML-OR	FK7
CL130400-100	CL1304XX-200	RECL1304-100	RTL	RTBCL-100	TML-OR	FK7
CL140800-100	CL1408XX-200	RECL1408-100	RTL	RTBCL-100	TML-OR	FK7
CL140200-100	CL1402XX-200	RECL1402-100	RTL	RTBCL-100	TML-OR	FK7
CL140700-100	CL1407XX-200	RECL1407-100	RTL	RTBCL-100	TML-OR	FK7
CL140300-100	CL1403XX-200	RECL1403-100	RTL	RTBCL-100	TML-OR	FK7
CL140400-100	CL1404XX-200	RECL1404-100	RTL	RTBCL-100	TML-OR	FK7
CL150800-100	CL1508XX-200	RECL1508-100	RTL	RTBCL-100	TML-OR	FK7
CL150200-100	CL1502XX-200	RECL1502-100	RTL	RTBCL-100	TML-OR	FK7
CL150700-100	CL1507XX-200	RECL1507-100	RTL	RTBCL-100	TML-OR	FK7
CL150300-100	CL1503XX-200	RECL1503-100	RTL	RTBCL-100	TML-OR	FK7
CL150400-100	CL1504XX-200	RECL1504-100	RTL	RTBCL-100	TML-OR	FK7

Common Replacement Parts
available on all listed heaters

High Limit Control	Check Valve
HLC-165	RV-M

CHART 2

Heaters with Thermostats

Temperature Range		Sensing Unit
ON	OFF	
80°F (27C)	100°F (38C)	FSU8
100°F (38C)	120°F (49C)	FSU10
120°F (49C)	140°F (60C)	FSU12
Adjustable 90° - 130°F (32° - 54°C)		FSU90-130

Example:

Model Number: CB115110-200
T-Stat Replacement: FSU10

ADAPTER FITTINGS

For the use of 0.75" or 1" ID heater hose, hose barb adapters are available. See below.

HB-1	1" NPT to 1" hose barb adapter. Installs in 1" NPT female inlet or outlet of the heater.
HB-3/4	1" NPT to 0.75" hose barb adapter. Installs in 1" NPT female inlet or outlet of the heater.

